Job Monitoring MIB, V0.86~~5~~

(This cover page is *not* part of the Internet-Draft)

From: Tom Hastings
Date: 09/19~~08/08~~/97
Version: 0.86~~5~~
File: ftp://ftp.pwg.org/pub/jmp/mibs/jmp-mib.doc .pdf jmp-mibr.doc .pdf .pdr

Status: Ninth~~Eighth~~ draft MIB that incorporates the agreements reached on the DL on issues in V0.85 which was released after the 8/8 meeting and the agreements reached at the JMP meeting on 9/19~~resolutions of issues 110 to 120 from the 8/8 JMP meeting~~. In addition to the changes listed in Ron's list, the JMP agreed to remove the finishing enums that IPP removed (because of a lack of a coordinate system specification for stapling), add private enum range for attributes to agree with IPP. See the change history in the separate file: changes.doc .pdf.

We agreed that the MIB specification is finished except for any editorial comments that people may have. See the separate issues.doc and .pdf file.

I've also produced a variation on this document which has all variable font (**jmp-mib.doc .pdf**) without revision marks. This is the version that the JMP should use to make comments. It has line numbers.

The MIB has been greatly simplified so that now there are only 18 objects in the MIB. There are 65 attributes.

INTERNET-DRAFT Ron Bergman
Dataproducts Corp.
Tom Hastings
Xerox Corporation
Scott Isaacson
Novell, Inc.
Harry Lewis
IBM Corp.
September 19~~August 8~~, 1997

Job Monitoring MIB - V0.86~~5~~

<draft-ietf-printmib-job-monitor-06~~5~~.txt>

Expires Mar 19~~Feb 8~~, 1997

Status of this Memo

Abstract

This Internet-Draft specifies a small set of read-only SNMP MIB objects for (1) monitoring the status and progress of print jobs (2) obtaining resource requirements before a job is processed, (3) monitoring resource consumption while a job is being processed and (4) collecting resource accounting data after the completion of a job. This MIB is intended to be implemented (1) in a printer or (2) in a server that supports one or more printers. Use of the object set is not limited to printing. However, support for services other than printing is outside the scope of this Job Monitoring MIB. Future extensions to this MIB may include, but are not limited to, fax machines and scanners.

TABLE OF CONTENTS

Job Monitoring MIB

1. Introduction

The Job Monitoring MIB is intended to be implemented by an agent within a printer or the first server closest to the printer, where the printer is either directly connected to the server only or the printer does not contain the job monitoring MIB agent. It is recommended that implementations place the SNMP agent as close as possible to the processing of the print job. This MIB applies to printers with and without spooling capabilities. This MIB is designed to be compatible with most current commonly-used job submission protocols. In most environments that support high function job submission/job control protocols, like ISO DPA[iso-dpa], those protocols would be used to monitor and manage print jobs rather than using the Job Monitoring MIB.

The Job Monitoring MIB consists of a General Group, a Job Submission ID Group, a Job Group, and an Attribute Group. Each group is a table. All accessible objects are read-only. The General Group contains general information that applies to all jobs in a job set. The Job Submission ID table maps the job submission ID that the client uses to identify a job to the **jmJobIndex** that the Job Monitoring Agent uses to identify jobs in the Job and Attribute tables. The Job table contains the MANDATORY integer job state and status objects. The Attribute table consists of multiple entries per job that specify (1) job and document identification and parameters, (2) requested resources, and (3) consumed resources during and after job processing/printing. A larger number of job attributes are defined as textual conventions that an agent SHALL return if the server or device implements the functionality so represented and the agent has access to the information.

1.1 Types of Information in the MIB

The job MIB is intended to provide the following information for the indicated Role Models in the Printer MIB[print-mib] (Appendix D - Roles of Users).

User:

Provide the ability to identify the least busy printer. The user will be able to determine the number and size of jobs waiting for each printer. No attempt is made to actually predict the length of time that jobs will take.

Provide the ability to identify the current status of the user's job (user queries).

Provide a timely indication that the job has completed and where it can be found.

Provide error and diagnostic information for jobs that did not successfully complete.

Operator:

Provide a presentation of the state of all the jobs in the print system.

Provide the ability to identify the user that submitted the print job.

Provide the ability to identify the resources required by each job.

Provide the ability to define which physical printers are candidates for the print job.

Provide some idea of how long each job will take. However, exact estimates of time to process a job is not being attempted. Instead, objects are included that allow the operator to be able to make gross estimates.

Capacity Planner:

Provide the ability to determine printer utilization as a function of time.

Provide the ability to determine how long jobs wait before starting to print.

Accountant:

Provide information to allow the creation of a record of resources consumed and printer usage data for charging users or groups for resources consumed.

Provide information to allow the prediction of consumable usage and resource need.

The MIB supports printers that can contain more than one job at a time, but still be usable for low end printers that only contain a single job at a time. In particular, the MIB supports the needs of Windows and other PC environments for managing low-end direct-connect (serial or parallel) and networked devices without unnecessary overhead or complexity, while also providing for higher end systems and devices.

1.2 Types of Job Monitoring Applications

The Job Monitoring MIB is designed for the following types of monitoring applications:

1. Monitor a single job starting when the job is submitted and ending a defined period after the job completes. The Job Submission ID table provides the map to find the specific job to be monitored.
2. Monitor all 'active' jobs in a queue, which this specification generalizes to a "job set". End users may use such a program when selecting a least busy printer, so the MIB is designed for such a program to start up quickly and find the information needed quickly without having to read all (completed) jobs in order to find the active jobs. System operators may also use such a program, in which case it would be running for a long period of time and may also be interested in the jobs that have completed. Finally such a program may be used to provide an enhanced console and logging capability.

3. Collect resource usage for accounting or system utilization purposes that copy the completed job statistics to an accounting system. It is recognized that depending on accounting programs to copy MIB data during the job-retention period is somewhat unreliable, since the accounting program may not be running (or may have crashed). Such a program is also expected to keep a shadow copy of the entire Job **Attribute** table including **completed, canceled, and aborted** jobs which the program updates on each polling cycle. Such a program polls at the rate of the persistence of the **Attribute** table. The design is not optimized to help such an application determine which jobs are **completed, canceled,** or **aborted**. Instead, the application SHALL query each job that the application's shadow copy shows was not **complete, canceled,** or **aborted** at the previous poll cycle to see if it is now **complete** or **canceled**, plus any new jobs that have been submitted.

The MIB provides a set of objects that represent a compatible subset of job and document attributes of the ISO DPA standard[iso-dpa] and the Internet Printing Protocol (IPP)[ipp-model], so that coherence is maintained between these two protocols and the information presented to end users and system operators by monitoring applications. However, the job monitoring MIB is intended to be used with printers that implement other job submitting and management protocols, such as IEEE 1284.1 (TIPSI)[tipsi], as well as with ones that do implement ISO DPA. Thus the job monitoring MIB does not require implementation of either the ISO DPA or IPP protocols.

The MIB is designed so that an additional MIB(s) can be specified in the future for monitoring multi-function (scan, FAX, copy) jobs as an augmentation to this MIB.

2. Terminology and Job Model

This section defines the terms that are used in this specification and the general model for jobs.

NOTE - Existing systems use conflicting terms, so these terms are drawn from the ISO 10175 Document Printing Application (DPA) standard[iso-dpa]. For example, PostScript systems use the term *session* for what is called a *job* in this specification and the term *job* to mean what is called a *document* in this specification. ~~PJL systems use the term *job* to mean what is called a *job* in this specification. PJL also supports multiple *documents* per job, but does not support specifying per-document attributes independently for each document.~~

Job: A~~a~~ unit of work whose results are expected together without interjection of unrelated results. A job contains one or more *documents*.

Job Set: A~~a~~ group of jobs that are queued and scheduled together according to a specified scheduling algorithm for a specified device or set of devices. For implementations that embed the SNMP agent in the device, the MIB job set normally represents *all* the jobs known to the device, so that the implementation only implements a single job set. If the

SNMP agent is implemented in a server that controls one or more devices, each MIB job set represents a job queue for (1) a specific device or (2) set of devices, if the server uses a single queue to load balance between several devices. Each job set is disjoint; no job SHALL be represented in more than one MIB job set.

Document: Aa sub-section within a job that contains print data and *document instructions* that apply to just the document.

Client: Tthe network entity that *end users* use to submit jobs to *spoolers*, *servers*, or *printers* and other *devices*, depending on the configuration, using any job submission protocol over a serial or parallel port to a directly-connected device or over the network to a networked-connected device.

Server: Aa network entity that accepts jobs from clients and in turn submits the jobs to *printers* and other *devices* that may be directly connected to the server via a serial or parallel port or may be on the network. A server MAY be a printer *supervisor* control program, or a print *spooler*.

Device: Aa hardware entity that (1) interfaces to humans ~~in human perceptible means~~, such as a device that produces marks on paper~~,~~ or scans marks on paper to produce an electronic representation~~s~~, (2) accesses digital media, such as~~or writes~~ CD-ROMs, or (3~~2~~) interfaces electronically to another device, such as sends FAX data to another FAX device.

Printer: Aa *device* that puts marks on media.

Supervisor: Aa server that contains a control program that controls a printer or other device. A supervisor is a client to the printer or other device.

Spooler: Aa server that accepts jobs, spools the data, and decides when and on which printer to print the job. A spooler is a client to a printer or a printer supervisor, depending on implementation.

Spooling: Tthe act of a *device* or *server* of (1) accepting jobs and (2) writing the job's attributes and document data on to secondary storage.

Queuing: Tthe act of a *device* or *server* of ordering (queuing) the jobs for the purposes of scheduling the jobs to be processed.

Monitor or Job Monitoring Application: Tthe SNMP management application that End Users, and System Operators use to monitor jobs using SNMP. A monitor MAY be either a separate application or MAY be part of the client that also submits jobs.

Accounting Application: Tthe SNMP management application that copies job information to some more permanent medium so that another application can perform accounting on the data for Accountants, Asset Managers, and Capacity Planners use.

Agent: The network entity that accepts SNMP requests from a *monitor* or *accounting application* and provides access to the instrumentation for managing jobs modeled by the management objects defined in the Job Monitoring MIB module for a *server* or a *device*.

Proxy: An agent that acts as a concentrator for one or more other agents by accepting SNMP operations on the behalf of one or more other agents, forwarding them on to those other agents, gathering responses from those other agents and returning them to the original requesting monitor.

User: A person that uses a client or a monitor.

End User: A user that uses a client to submit a print job.

System Operator: A user that uses a monitor to monitor the system and carries out tasks to keep the system running.

System Administrator: A user that specifies policy for the system.

Job Instruction: An instruction specifying how, when, or where the job is to be processed. Job instructions MAY be passed in the job submission protocol or MAY be embedded in the document data or a combination depending on the job submission protocol and implementation.

Document Instruction: An instruction specifying how to process the document. Document instructions MAY be passed in the job submission protocol separate from the actual document data, or MAY be embedded in the document data or a combination, depending on the job submission protocol and implementation.

SNMP Information Object: A name, value-pair that specifies an action, a status, or a condition in an SNMP MIB. Objects are identified in SNMP by an OBJECT IDENTIFIER.

Attribute: A name, value-pair that specifies a job or document instruction, a status, or a condition of a job or a document that has been submitted to a server or device. A particular attribute NEED NOT be present in each job instance. In other words, attributes are present in a job instance only when there is a need to express the value, either because (1) the client supplied a value in the job submission protocol, (2) the document data contained an embedded attribute, or (3) the server or device supplied a default value. An agent SHALL represent an attribute as an entry (row) in the Attribute table in this MIB in which entries are present only when necessary. Attributes are identified in this MIB by an enum.

Job Monitoring (using SNMP): The activity of a management application of accessing the MIB and (1) identifying jobs in the job tables being processed by the server, printer or other devices, and (2) displaying information to the user about the processing of the job.

Job Accounting: The activity of a management application of accessing the MIB and recording what happens to the job during and after the processing of the job.

2.1 System Configurations for the Job Monitoring MIB

This section enumerates the three configurations in which the Job Monitoring MIB is intended to be used. To simplify the pictures, the *devices* are shown as *printers*. See section 1.1 entitled "Types of Information in the MIB".

The diagram in the Printer MIB[print-mib] entitled: "One Printer's View of the Network" is assumed for this MIB as well. Please refer to that diagram to aid in understanding the following system configurations.

2.1.1 Configuration 1 - client-printer

In the **client-printer** configuration 1, the **client**(s) submit jobs directly to the **printer**, either by some direct connect, or by network connection.

The job submitting **client** and/or **monitoring application** monitor jobs by communicating directly with an agent that is part of the **printer**. The agent in the **printer** SHALL keep the job in the Job Monitoring MIB as long as the job is in the **printer**, plus a defined time period after the job enters the **completed** state in which accounting programs can copy out the accounting data from the Job Monitoring MIB.



Figure 2-1 - Configuration 1 - client-printer - agent in the printer

The Job Monitoring MIB is designed to support the following relationships (not shown in Figure 2-1):

1. Multiple **clients** MAY submit jobs to a **printer**.
2. Multiple **clients** MAY monitor a **printer**.

3. Multiple **monitors** MAY monitor a **printer**.
4. A **client** MAY submit jobs to multiple **printers**.
5. A **monitor** MAY monitor multiple **printers**.

2.1.2 Configuration 2 - client-server-printer - agent in the server

In the **client-server-printer** configuration 2, the **client**(s) submit jobs to an intermediate **server** by some network connection, *not* directly to the **printer**. While configuration 2 is included, the design center for this MIB is configurations 1 and 3.

The job submitting **client** and/or **monitoring application** monitor jobs by communicating directly with:

A Job Monitoring MIB agent that is part of the **server** (or a front for the server)

There is no SNMP Job Monitoring MIB agent in the **printer** in configuration 2, at least that the client or monitor are aware. In this configuration, the agent SHALL return the current values of the objects in the Job Monitoring MIB both for jobs the server keeps and jobs that the server has submitted to the **printer**. The Job Monitoring MIB agent SHALL obtain the required information from the **printer** by a method that is beyond the scope of this document. The agent in the **server** SHALL keep the job in the Job Monitoring MIB in the server as long as the job is in the **printer**, plus a defined time period after the job enters the **completed** state in which accounting programs can copy out the accounting data from the Job Monitoring MIB.



Figure 2-2 - Configuration 2 - client-server-printer - agent in the server

The Job Monitoring MIB is designed to support the following relationships (not shown in Figure 2-2):

1. Multiple **clients** MAY submit jobs to a **server**.
2. Multiple **clients** MAY monitor a **server**.
3. Multiple **monitors** MAY monitor a **server**.
4. A **client** MAY submit jobs to multiple **servers**.
5. A **monitor** MAY monitor multiple **servers**.
6. Multiple **servers** MAY submit jobs to a **printer**.
7. Multiple **servers** MAY control a **printer**.

2.1.3 Configuration 3 - client-server-printer - client monitors printer agent and server

In the **client-server-printer** configuration 3, the **client**(s) submit jobs to an intermediate **server** by some network connection, *not* directly to the **printer**. That server does *not* contain a Job Monitoring MIB agent.

The job submitting **client** and/or **monitoring application** monitor jobs by communicating directly with:

1. The **server** using some undefined protocol to monitor jobs in the server (that does not contain the Job Monitoring MIB) AND

2. A Job Monitoring MIB agent that is part of the **printer** to monitor jobs after the **server** passes the jobs to the **printer**. In such configurations, the **server** deletes its copy of the job from the **server** after submitting the job to the printer usually almost immediately (before the job does much processing, if any)**.**

In configuration 3, the agent (in the **printer**) SHALL keep the values of the objects in the Job Monitoring MIB that the agent implements updated for a job that the server has submitted to the printer. The agent SHALL obtain information about the jobs submitted to the printer from the server (either in the job submission protocol, in the document data, or by direct query of the server), in order to populate some of the objects the Job Monitoring MIB in the printer. The agent in the printer SHALL keep the job in the Job Monitoring MIB as long as the job is in the Printer, and longer in order to implement the **completed** state in which monitoring programs can copy out the accounting data from the Job Monitoring MIB.



Figure 2-3 - Configuration 3 - client-server-printer - client monitors printer agent and server

The Job Monitoring MIB is designed to support the following relationships (not shown in Figure 2-3):

1. Multiple **clients** MAY submit jobs to a **server**.
2. Multiple **clients** MAY monitor a **server**.
3. Multiple **monitors** MAY monitor a **server**.

4. A **client** MAY submit jobs to multiple **servers**.
5. A **monitor** MAY monitor multiple **servers**.
6. Multiple **servers** MAY submit jobs to a **printer**.
7. Multiple **servers** MAY control a **printer**.

3. Managed Object Usage

This section describes the usage of the objects in the MIB.

3.1 Conformance Considerations

In order to achieve interoperability between job monitoring applications and job monitoring agents, this specification includes the conformance requirements for both monitoring applications and agents.

3.1.1 Conformance Terminology

This specification uses the verbs: "SHALL", "SHOULD", "MAY", and "NEED NOT" to specify conformance requirements according to RFC 2119 [req-words] as follows:

- "SHALL": indicates an action that the subject of the sentence must implement in order to claim conformance to this specification
- "MAY": indicates an action that the subject of the sentence does not have to implement in order to claim conformance to this specification, in other words that action is an implementation option
- "NEED NOT": indicates an action that the subject of the sentence does not have to implement in order to claim conformance to this specification. The verb "NEED NOT" is used instead of "may not", since "may not" sounds like a prohibition.
- "SHOULD": indicates an action that is recommended for the subject of the sentence to implement, but is not required, in order to claim conformance to this specification.

3.1.2 Agent Conformance Requirements

A conforming agent:

1. SHALL implement *all* MANDATORY groups in this specification.
2. SHALL implement any attributes if (1) the server or device supports the functionality represented by the attribute and (2) the information is available to the agent.
3. SHOULD implement both forms of an attribute if it implements an attribute that permits a choice of INTEGER and OCTET STRING forms, since

implementing both forms may help management applications by giving them a choice of representations, since the representation are equivalent. See the **JmAttributeTypeTC** textual-convention.

NOTE - This MIB, like the Printer MIB, is written following the subset of SMIv2 that can be supported by SMIv1 and SNMPv1 implementations.

3.1.2.1 MIB II System Group objects

The Job Monitoring MIB agent SHALL implement all objects in the System Group of MIB-II[mib-II], whether the Printer MIB[print-mib] is implemented or not.

3.1.2.2 MIB II Interface Group objects

The Job Monitoring MIB agent SHALL implement all objects in the Interfaces Group of MIB-II[mib-II], whether the Printer MIB[print-mib] is implemented or not.

3.1.2.3 Printer MIB objects

If the agent is providing access to a device that is a printer, the agent SHALL implement all of the MANDATORY objects in the Printer MIB[print-mib] and all the objects in other MIBs that conformance to the Printer MIB requires, such as the Host Resources MIB[hr-mib]. If the agent is providing access to a server that controls one or more direct-connect or networked printers, the agent NEED NOT implement the Printer MIB and NEED NOT implement the Host Resources MIB.

3.1.3 Job Monitoring Application Conformance Requirements

A conforming job monitoring application:

1. SHALL accept the full syntactic range for all objects in all MANDATORY groups and all MANDATORY attributes that are required to be implemented by an agent according to Section 3.1.2 and SHALL either present them to the user or ignore them.
2. SHALL accept the full syntactic range for *all* attributes, including enum and bit values specified in this specification and additional ones that may be registered with IANA and SHALL either present them to the user or ignore them. In particular, a conforming job monitoring application SHALL not malfunction when receiving any standard or registered enum or bit values. See Section 3.6 entitled "IANA Considerations".
3. SHALL NOT fail when operating with agents that materialize attributes *after* the job has been submitted, as opposed to when the job is submitted.
4. SHALL, if it supports a time attribute, accept either form of the time attribute, since agents are free to implement either time form.

3.2 The Job Tables and the Oldest Active and Newest Active Indexes

The **jmJobTable** and **jmAttributeTable** contain objects and attributes, respectively, for each job in a job set. These first two indexes are:

1. jmGeneralJobSetIndex - which job set
2. jmJobIndex - which job in the job set

In order for a monitoring application to quickly find that active jobs (jobs in the **pending**, **processing**, or **processingStopped** states), the MIB contains two indexes:

1. **jmGeneralOldestActiveJobIndex** - the index of the active job that has been in the tables the longest.
2. **jmGeneralNewestActiveJobIndex** - the index of the active job that has been most recently added to the tables.

The agent SHALL assign the next incremental value of **jmJobIndex** to the job, when a new job is accepted by the server or device to which the agent is providing access. If the incremented value of **jmJobIndex** would exceed the implementation-defined maximum value for **jmJobIndex**, the agent SHALL 'wrap' back to 1. An agent uses the resulting value of **jmJobIndex** for storing information in the **jmJobTable** and the **jmAttributeTable** about the job.

It is recommended that the largest value for **jmJobIndex** be much larger than the maximum number of jobs that the implementation can contain at a single time, so as to minimize the premature re-use of a **jmJobIndex** value for a newer job while clients retain the same 'stale' value for an older job.

It is recommended that agents that are providing access to servers/devices that already allocate job-identifiers for jobs as integers use the same integer value for the **jmJobIndex**. Then ~~the jobs will have the same job identifier value as the **jmJobIndex** value, so that users viewing jobs by~~ management applications using this MIB and applications using other protocols will see the same job identifiers for the same jobs. Agents providing access to systems that contain jobs with a job identifier of **0** SHALL map the job identifier value **0** to a **jmJobIndex** value that is one higher than the highest job identifier value that any job can have on that system. Then only job 0 will have a different job-identifier value than the job's **jmJobIndex** value.

NOTE - If a server or device accepts jobs using multiple job submission protocols, it may be difficult for the agent to meet the recommendation to use the job-identifier values that the server or device assigns as the **jmJobIndex** value, unless the server/device assigns job-identifiers for each of its job submission protocols from the same job-identifier number space.

Each time a new job is accepted by the server or device that the agent is providing access to AND that job is to be 'active' (**pending**, **processing**, or **processingStopped**, but not **pendingHeld**), the agent SHALL copy the value of the job's **jmJobIndex** to the

jmGeneralNewestActiveJobIndex object. If the new job is to be 'inactive' (**pendingHeld** state), the agent SHALL not change the value of **jmGeneralNewestActiveJobIndex** object (though the agent SHALL assign the next incremental **jmJobIndex** value to the job).

When a job transitions from one of the 'active' job states (**pending**, **processing**, **processingStopped**) to one of the 'inactive' job states (**pendingHeld**, **completed**, **canceled**, or **aborted),** with a **jmJobIndex** value that matches the **jmGeneralOldestActiveJobIndex** object, the agent SHALL advance (or wrap) the value to the next oldest 'active' job, if any. See the **JmJobStateTC** textual-convention for a definition of the job states.

Whenever a job transitions from one of the 'inactive' job states to one of the 'active' job states (from **pendingHeld** to **pending** or **processing**), the agent SHALL update the value of either the **jmGeneralOldestActiveJobIndex** or the **jmGeneralNewestActiveJobIndex** objects, or both, if the job's **jmJobIndex** value is outside the range between **jmGeneralOldestActiveJobIndex** and **jmGeneralNewestActiveJobIndex**.

When all jobs become 'inactive', i.e., enter the **pendingHeld**, **completed**, **canceled,** or **aborted** states, the agent SHALL set the value of both the **jmGeneralOldestActiveJobIndex** and **jmGeneralNewestActiveJobIndex** objects to **0**.

NOTE - Applications that wish to efficiently access all of the active jobs MAY use **jmGeneralOldestActiveJobIndex** value to start with the oldest active job and continue until they reach the index value equal to **jmGeneralNewestActiveJobIndex,** skipping over any **pendingHeld**, **completed**, **canceled, or aborted** jobs that might intervene**.**

If an application detects that the **jmGeneralNewestActiveJobIndex** is smaller than **jmGeneralOldestActiveJobIndex**, the job index has wrapped. In this case, the application SHALL reset the index to **1** when the end of the table is reached and continue the GetNext operations to find the rest of the active jobs.

NOTE - Applications detect the end of the **jmAttributeTable** table when the OID returned by the GetNext operation is an OID in a different MIB. There is no object in this MIB that specifies the maximum value for the **jmJobIndex** supported by the implementation.

When the server or device is power-cycled, the agent SHALL remember the next **jmJobIndex** value to be assigned, so that new jobs are not assigned the same **jmJobIndex** as recent jobs before the power cycle.

3.3 The Attribute Mechanism

Attributes are similar to information objects, except that attributes are identified by an enum, instead of an OID, so that attributes may be registered without requiring a new MIB. Also an implementation that does not have the functionality represented by the attribute can omit the attribute entirely, rather than having to return a distinguished value. The agent is free to materialize an attribute in the **jmAttributeTable** as soon as the agent is aware of the value of the attribute.

The agent materializes job attributes in a four-indexed **jmAttributeTable**:

1. jmGeneralJobSetIndex - which job set
2. jmJobIndex - which job in the job set
3. jmAttributeTypeIndex - which attribute
4. jmAttributeInstanceIndex - which attribute instance for those attributes that can have multiple values per job.

Some attributes represent information about a job, such as a file-name, a document-name, a submission-time or a completion time. Other attributes represent resources required, e.g., a medium or a colorant, etc. to process the job before the job starts processing OR to indicate the amount of the resource consumed during and after processing, e.g., pages completed or impressions completed. If both a required and a consumed value of a resource is needed, this specification assigns two separate attribute enums in the textual convention.

NOTE - The table of contents lists all the attributes in order. This order is the order of enum assignments which is the order that the SNMP GetNext operation returns attributes. Most attributes apply to all three configurations covered by this MIB specification (see section 2.1 entitled "System Configurations for the Job Monitoring MIB"). Those attributes that apply to a particular configuration are indicated as '**Configuration *n*:**' and SHALL NOT be used with other configurations.

3.3.1 Conformance of Attribute Implementation

An agent SHALL implement any attribute if (1) the server or device supports the functionality represented by the attribute and (2) the information is available to the agent. The agent MAY create the attribute row in the **jmAttributeTable** when the information is available or MAY create the row earlier with the designated 'unknown' value appropriate for that attribute. See next section.

If the server or device does not implement or does not provide access to the information about an attribute, the agent SHOULD NOT create the corresponding row in the **jmAttributeTable**.

3.3.2 Useful, 'Unknown', and 'Other' Values for Objects and Attributes

Some attributes have a 'useful' Integer32 value, some have a 'useful' OCTET STRING value, some MAY have either or both depending on implementation, and some MUST have both. See the **JmAttributeTypeTC** textual convention for the specification of each attribute.

SNMP requires that if an object cannot be implemented because its values cannot be accessed, then a compliant agent SHALL return an SNMP error in SNMPv1 or an exception value in SNMPv2. However, this MIB has been designed so that 'all' objects can and SHALL be implemented by an agent, so that neither the SNMPv1 error nor the SNMPv2 exception value SHALL be generated by the agent. This MIB has also been designed so that when an agent materializes an attribute, the agent SHALL materialize a row consisting of both the **jmAttributeValueAsInteger** and **jmAttributeValueAsOctets** objects.

In general, values for objects and attributes have been chosen so that a management application will be able to determine whether a 'useful', 'unknown', or 'other' value is available. When a useful value is not available for an object that agent SHALL return a zero-length string for octet strings, the value '**unknown(2)'** for enums, a '**0'** value for an object that represents an index in another table, and a value '**-2'** for counting integers.

Since each attribute is represented by a row consisting of both the **jmAttributeValueAsInteger** and **jmAttributeValueAsOctets** MANDATORY objects, SNMP requires that the agent SHALL always create an attribute row with both objects specified. However, for most attributes the agent SHALL return a "useful" value for one of the objects and SHALL return the 'other' value for the other object. For integer only attributes, the agent SHALL always return a zero-length string value for the **jmAttributeValueAsOctets** object. For octet string only attributes, the agent SHALL always return a **'-1'** value for the **jmAttributeValueAsInteger** object.

3.3.3 Data Sub-types and Attribute Naming Conventions

Many attributes are sub-typed to give a more specific data type than **Integer32** or **OCTET STRING**. The data sub-type of each attribute is indicated on the first line(s) of the description. Some attributes have several different data sub-type representations. When an attribute has both an **Integer32** data sub-type and an **OCTET STRING** data sub-type, the attribute can be represented in a single row in the **jmAttributeTable.** In this case, the data sub-type name is not included as the last part of the name of the attribute, e.g., **documentFormat(38)** which is both an enum and/or a name. When the data sub-types cannot be represented by a single row in the **jmAttributeTable**, each such representation is considered a separate attribute and is assigned a separate name and enum value. For these attributes, the name of the data sub-type is the last part of the name of

765 the attribute: **Name**, **Index**, **DateAndTime**, **TimeStamp**, etc. For example,
766 **documentFormatIndex(37)** is an index.

767 NOTE: The Table of Contents also lists the data sub-type and/or data sub-types of each
768 attribute, using the textual-convention name when such is defined. The following
769 abbreviations are used in the Table of Contents as shown:

'Int32(-2..)'	Integer32(-2..2147483647)
'Int32(0..)'	Integer32(0..2147483647)
'Int32(1..)'	Integer32(1..2147483647)
'Int32(m..n)'	For all other Integer ranges, the lower and upper bound of the range is indicated.
'UTF8String63'	JmUTF8StringTC(SIZE(0..63))
'JobString63'	JmJobStringTC(SIZE(0..63))
'Octets63'	OCTET STRING(SIZE(0..63))
'Octets(m..n)'	For all other OCTET STRING ranges, the exact range is indicated.

770 ### 3.3.4 Single-Value (Row) Versus Multi-Value (MULTI-ROW) Attributes

771 Most attributes SHALL have only one row per job. However, a few attributes can have
772 multiple values per job or even per document, where each value is a separate row in the
773 **jmAttributeTable**. Unless indicated with '**MULTI-ROW:**' in the **JmAttributeTypeTC**
774 description, an agent SHALL ensure that each attribute occurs only once in the
775 **jmAttributeTable** for a job. Most of the '**MULTI-ROW**' attributes do not allow
776 duplicate values, i.e., the agent SHALL ensure that each value occurs only once for a job.
777 Only if the specification of the '**MULTI-ROW**' attribute also says "the values NEED NOT
778 be unique" can the agent allow duplicate values to occur for the job.

779 NOTE - Duplicates are allowed for 'extensive' '**MULTI-ROW**' attributes, such as
780 **fileName(34)** or **documentName(35)** which are specified to be 'per-document' attributes,
781 but are *not* allowed for 'intensive' '**MULTI-ROW**' attributes, such as
782 **mediumConsumed(171)** and **documentFormat(38)** which are specified to be 'per-job'
783 attributes.

784 ### 3.3.5 Requested Attributes

785 A number of attributes record requirements for the job. Such attribute names end with the
786 word **'Requested'**. In the interests of brevity, the phrase 'requested' SHALL mean: (1)
787 requested by the client (or intervening server) in the job submission protocol and MAY
788 also mean (2) embedded in the submitted document data, and/or (3) defaulted by the
789 recipient device or server with the same semantics as if the requester had supplied,
790 depending on implementation.

3.3.6 Consumption Attributes

A number of attributes record consumption. Such attribute names end with the word **'Completed'** or **'Consumed'**. If the job has not yet consumed what that resource is metering, the agent either: (1) SHALL return the value **0** or (2) SHALL *not* add this attribute to the **jmAttributeTable** until the consumption begins. In the interests of brevity, the semantics for **0** is specified once here and is *not* repeated for each consumptive attribute specification.

3.3.7 Index Value Attributes

A number of attributes are indexes in other tables. Such attribute names end with the word **'Index'**. If the agent has not (yet) assigned an index value for a particular index attribute for a job, the agent SHALL either: (1) return the value **0** or (2) *not* add this attribute to the **jmAttributeTable** until the index value is assigned. In the interests of brevity, the semantics for **0** is specified once here and is *not* repeated for each index attribute specification.

3.4 Job Identification

There are a number of attributes that permit a user, operator or system administrator to identify jobs of interest, such as **jobURI**, **jobName**, **jobOriginatingHost**, etc. In addition, there is a **jmJobSubmissionID** object that is a text string table index. Being a table index allows a monitoring application to quickly locate and identify a particular job of interest that was submitted from a particular client by the user invoking the monitoring application. The Job Monitoring MIB needs to provide for identification of the job at both sides of the job submission process. The primary identification point is the client side. The **jmJobSubmissionID** allows the monitoring application to identify the job of interest from all the jobs currently "known" by the server or device. The value of jmJobSubmissionID can be assigned by either the client's local system or a downstream server or device. The point of assignment depends on the job submission protocol in use.

The server/device-side identifier, called the **jmJobIndex** object, SHALL be assigned by the SNMP Job Monitoring MIB agent when the server or device accepts the jobs from submitting clients. The **jmJobIndex** object allows the interested party to obtain all objects desired that relate to a particular job. See Section 3.2, entitled 'The Job Tables and the Oldest Active and Newest Active Indexes' for the specification of how the agent SHALL assign the **jmJobIndex** values.

~~NOTE - For a number of job submission protocols the server/device assigns an integer job identifier when accepting a job so that the submitting client can reference the job in subsequent protocol operations (For example, see IPP [ipp]). For such implementations,~~

~~it is recommended that the value of the job identifier and the value of jmJobIndex be the same, so that~~

The MIB provides a mapping table that maps each **jmJobSubmissionID** value to the corresponding **jmJobIndex** value generated by the agent, so that an application can determine the correct value for the **jmJobIndex** value for the job of interest in a single Get operation, given the Job Submission ID. See the **jmJobIDGroup**.

The **jobName** attribute provides a name that the user supplies as a job attribute with the job. The **jobName** attribute is not necessarily unique, even for one user, let alone across users.

3.5 Internationalization Considerations

This section describes the internationalization considerations included in this MIB.

3.5.1 Text generated by the server or device

There are a few objects and attributes generated by the server or device that SHALL be~~are~~ represented using the Universal Multiple-Octet Coded Character Set (UCS) [ISO-10646] ~~encoded as an octet string using the UTF-8 [UTF-8] character encoding scheme~~. ~~The '**JmUTF8StringTC**' textual convention is used to indicate UTF-8 text strings.~~ These objects and attributes are always supplied (if implemented) by the agent, not by the job submitting client:

1. jmGeneralJobSetName object
2. processingMessage(6) attribute
3. physicalDevice(32) (name value) attribute

The character encoding scheme~~coded character set~~ for representing these objects and attributes SHALL be UTF-8 as recommended by RFC 2130 [RFC 2130] and the "IETF Policy on Character Sets and Language" [char-set policy]. The 'JmUTF8StringTC' textual convention is used to indicate UTF-8 text strings.

NOTE - For strings in 7-bit US-ASCII, there is no impact since the UTF-8 representation of 7-bit ASCII is identical to the US-ASCII [US-ASCII] encoding.

3.5.2 Text generated by the job submitter

All of the objects and attributes represented by the '**JmJobStringTC**' textual-convention are either (1) supplied in the job submission protocol by the client that submits the job to the server or device or (2) are defaulted by the server or device if the job submitting client does not supply values. The agent SHALL represent these objects and attributes in the MIB either (1) in the coded character set as they were submitted or (2) MAY convert the coded character set to another coded character set or encoding scheme. In any case, the

resulting coded character set representation SHOULD be UTF-8 [UTF-8], but SHALL be one in which the code positions from 0 to 31 SHALL not be used, 32 to 127 SHALL be US-ASCII [US-ASCII], 127 SHALL be unused, and the remaining code positions 128 to 255 SHALL represent single-byte or multi-byte graphic characters structured according to ISO 2022 [ISO 2022] or SHALL be unused.

The coded character set SHALL be one of the ones registered with IANA [IANA] and SHALL be identified by the **jobCodedCharSet** attribute in the **jmJobAttributeTable** for the job. If the agent does not know what coded character set was used by the job submitting client, the agent SHALL either (1) return the '**unknown(2)**' value for the **jobCodedCharSet** attribute or (2) not return the **jobCodedCharSet** attribute for the job.

Examples of coded character sets which meet this criteria for use as the value of the **jobCodedCharSet** job attribute are: US-ASCII [US-ASCII], ISO 8859-1 (Latin-1) [ISO 8859-1], any ISO 8859-n, HP Roman8, IBM Code Page 850, Windows Default 8-bit set, UTF-8 [UTF-8], US-ASCII plus JIS X0208-1990 Japanese [JIS X0208], US-ASCII plus GB2312-1980 PRC Chinese [GB2312]. See the IANA registry of coded character sets [IANA charsets].

Examples of coded character sets which do not meet this criteria are: national 7-bit sets conforming to ISO 646 (except US-ASCII), EBCDIC, and ISO 10646 (Unicode) [ISO-10646]. In order to represent Unicode characters, the UTF-8 [UTF-8] encoding scheme SHALL be used which has been assigned the MIBenum value of '106' by IANA.

The **jobCodedCharSet** attribute uses the imported **'CodedCharSet'** textual-convention from the Printer MIB [printmib].

3.5.3 'DateAndTime' for representing the date and time

This MIB also contains objects that are represented using the **DateAndTime** textual convention from SMIv2 [SMIv2-TC]. The job management application SHALL display such objects in the locale of the user running the monitoring application.

3.6 IANA Considerations

During the development of this standard, the Printer Working Group (PWG) working with IANA [iana] will register additional enums while the standard is in the proposed and draft states according to the procedures described in this section. IANA will handle registration of additional enums after this standard is approved in cooperation with an IANA-appointed registration editor from the PWG according to the procedures described in this section:

3.6.1 IANA Registration of enums

This specification uses textual conventions to define enumerated values (enums) and bit values. Enumerations (enums) and bit values are sets of symbolic values defined for use with one or more objects or attributes. All enumeration sets and bit value sets are assigned a symbolic data type name (textual convention). As a convention the symbolic name ends in "**TC**" for textual convention. These enumerations are defined at the beginning of the MIB module specification.

This working group has defined several type of enumerations for use in the Job Monitoring MIB and the Printer MIB[print-mib]. These types differ in the method employed to control the addition of new enumerations. Throughout this document, references to "type n enum", where n can be 1, 2 or 3 can be found in the various tables. The definitions of these types of enumerations are:

3.6.1.1 Type 1 enumerations

Type 1 enumeration: All the values are defined in the Job Monitoring MIB specification (RFC for the Job Monitoring MIB). Additional enumerated values require a new RFC.

There are no type 1 enums in the current draft.

3.6.1.2 Type 2 enumerations

Type 2 enumeration: An initial set of values are defined in the Job Monitoring MIB specification. Additional enumerated values are registered after review by this working group or an editor appointed by IANA after this working group is no longer active.

The following type 2 enums are contained in the current draft :

1. JmUTF8StringTC
2. JmJobStringTC
3. JmTimeStampTC
4. JmFinishingTC [same enum values as IPP "finishing" attribute]
5. JmPrintQualityTC [same enum values as IPP "print-quality" attribute]
6. JmTonerEconomyTC
7. JmMediumTypeTC
8. JmJobSubmissionTypeTC
9. JmJobStateTC [same enum values as IPP "job-state" attribute]
10. JmAttributeTypeTC

For those textual conventions that have the same enum values as the indicated IPP Job attribute SHALL be simultaneously registered by IANA for use with IPP [ipp-model] and the Job Monitoring MIB.

3.6.1.3 Type 3 enumeration

Type 3 enumeration: An initial set of values are defined in the Job Monitoring MIB specification. Additional enumerated values are registered through IANA without working group review.

There are no type 3 enums in the current draft.

3.6.2 IANA Registration of type 2 bit values

This draft contains the following type 2 bit value textual-conventions:

1. JmJobServiceTypesTC
2. JmJobStateReasons1TC
3. JmJobStateReasons2TC
4. JmJobStateReasons3TC
5. JmJobStateReasons4TC

These textual-conventions are defined as bits in an Integer so that they can be used with SNMPv1 SMI. The **jobStateReasons*N*** (*N*=1..4) attributes are defined as bit values using the corresponding **JmJobStateReasons*N*TC** textual-conventions.

The registration of **JmJobServiceTypesTC** and **JmJobStateReasons*N*TC** bit values SHALL follow the procedures for a type 2 enum as specified in Section 3.6.1.2.

3.6.3 IANA Registration of Job Submission Id Formats

In addition to enums and bit values, this specification assigns a single ASCII digit or letter to various job submission ID formats. See the **JmJobSubmissionIDTypeTC** textual-convention and the object. The registration of **jmJobSubmissionID** format numbers SHALL follow the procedures for a type 2 enum as specified in Section 3.6.1.2.

3.6.4 IANA Registration of MIME types/sub-types for document-formats

The **documentFormat(38)** attribute has MIME type/sub-type values for indicating document formats which IANA registers as "media type" names. The values of the **documentFormat(38)** attribute are the same as the corresponding Internet Printing Protocol (IPP) "document-format" Job attribute values [ipp-model].

3.7 Security Considerations

3.7.1 Read-Write objects

All objects are read-only, greatly simplifying the security considerations. If another MIB augments this MIB, that MIB might accept SNMP Write operations to objects in that MIB whose effect is to modify the values of read-only objects in this MIB. However, that

MIB SHALL have to support the required access control in order to achieve security, not this MIB.

3.7.2 Read-Only Objects In Other User's Jobs

The security policy of some sites MAY be that unprivileged users can only get the objects from jobs that they submitted, plus a few minimal objects from other jobs, such as the **jmJobKOctetsRequested** and **jmJobKOctetsProcessed** objects**,** so that a user can tell how busy a printer is. Other sites MAY allow all unprivileged users to see all objects of all jobs. This MIB does not require, nor does it specify how, such restrictions would be implemented. A monitoring application SHOULD enforce the site security policy with respect to returning information to an unprivileged end user that is using the monitoring application to monitor jobs that do not belong to that user, i.e., the **jmJobOwner** object in the **jmJobTable** does not match the user's user name.

An operator is a privileged user that would be able to see all objects of all jobs, independent of the policy for unprivileged users.

3.8 Notifications

This MIB does not specify any notifications. For simplicity, management applications are expected to poll for status. The **jmGeneralJobPersistence** and **jmGeneralAttributePersistence** objects assist an application to determine the polling rate. The resulting network traffic is not expected to be significant.

4. MIB specification

The following pages constitute the actual Job Monitoring MIB.

```
980  Job-Monitoring-MIB DEFINITIONS ::= BEGIN
981
982  IMPORTS
         MODULE-IDENTITY, OBJECT-TYPE, experimental, Integer32
                                                          FROM SNMPv2-SMI
         TEXTUAL-CONVENTION                               FROM SNMPv2-TC
         MODULE-COMPLIANCE, OBJECT-GROUP                  FROM SNMPv2-CONF;
         -- The following textual-conventions are needed
         -- to implement certain attributes, but are *not*
         -- needed to compile this MIB.  They are
         -- provided here for convenience:
         -- hrDeviceIndex                                 FROM HOST-RESOURCES-MIB
         -- DateAndTime                                   FROM SNMPv2-TC
         -- PrtInterpreterLangFamilyTC,
         -- CodedCharSet                                  FROM Printer-MIB
983
984  -- Use the experimental (54) OID assigned to the Printer MIB[print-mib]
985  -- before it was published as RFC 1759.
986  -- Upon publication of the Job Monitoring MIB as an RFC, delete this
987  -- comment and the line following this comment and change the
988  -- reference of { temp 105 } (below) to { mib-2 X }.
989  -- This will result in changing:
990  -- 1 3 6 1 3 54 jobmonMIB(105)    to:
991  -- 1 3 6 1 2  1 jobmonMIB(X)
992  -- This will make it easier to translate prototypes to
993  -- the standard namespace because the lengths of the OIDs won't
994  -- change.
995  temp OBJECT IDENTIFIER ::= { experimental 54 }
996
997  jobmonMIB MODULE-IDENTITY
998      LAST-UPDATED "9709190808 0000Z"
999      ORGANIZATION "IETF Printer MIB Working Group"
1000     CONTACT-INFO
1001         "Tom Hastings
1002         Postal:  Xerox Corp.
1003                  Mail stop ESAE-231
1004                  701 S. Aviation Blvd.
1005                  El Segundo, CA 90245
1006
1007         Tel:     (301)333-6413
1008         Fax:     (301)333-5514
1009         E-mail:  hastings@cp10.es.xerox.com
1010
1011         Send comments to the printmib WG using the Job Monitoring
1012         Project (JMP) Mailing List:  jmp@pwg.org
1013
1014         To learn how to subscribe to the JMP mailing list,
1015         send email to:  jmp-request@pwg.org
1016
```

```
                For further information, access the PWG web page under 'JMP':
                http://www.pwg.org/"
        DESCRIPTION
                "The MIB module for monitoring job in servers, printers, and other devices.

                File: draft-ietf-printmib-job-monitor-065.txt
                Version: 0.8655"
        ::= { temp 105 }


-- Textual conventions for this MIB module


JmUTF8StringTC ::= TEXTUAL-CONVENTION
        DISPLAY-HINT "255a"
        STATUS      current
        DESCRIPTION
                "To facilitate internationalization, this TC represents information taken from the ISO/IEC IS
                10646-1 character set, encoded as an octet string using the UTF-8 character encoding scheme.

                NOTE - The values of objects and attributes using this textual convention are generated by the
                server or the device, not by the job submitter."
        REFERENCE
                "See section 3.5.1, entitled: 'Text generated by the server or device'."
        SYNTAX      OCTET STRING (SIZE (0..63))


JmJobStringTC ::= TEXTUAL-CONVENTION
        STATUS      current
        DESCRIPTION
                "To facilitate internationalization, this TC represents information using any coded character set
                registered by IANA as specified in section 3.5.2that has the following properties: (1) code
                positions from 0 to 31 SHALL not be used, (2) 32 to 127 SHALL be US-ASCII [US-ASCII],
                (3) 127 SHALL be unused, and (4) the remaining code positions 128 to 255 SHALL represent
                single-byte or multi-byte graphic characters structured according to ISO 2022 [ISO 2022] or
                SHALL be unused. While it is recommended that the coded character set be UTF-8 [UTF-8],
                the actual coded character set SHALL be indicated by the value of the jobCodedCharSet(7)
                attribute for the job.

                NOTE - The values of objects and attributes using this textual convention are either generated
                by the job submitter or defaulted by the server or device when the job submitter does not supply
                values."
        REFERENCE
```

"See section 3.5.2, entitled: 'Text generated by the job submitter'."
SYNTAX OCTET STRING (SIZE (0..63))

JmTimeStampTC ::= TEXTUAL-CONVENTION
STATUS current
DESCRIPTION
"The simple time at which an event took place. The units SHALL be in seconds since the system was booted.

NOTE - **JmTimeStampTC** is defined in units of seconds, rather than 100ths of seconds, so as to be simpler for agents to implement (even if they have to implement the 100ths of a second to comply with implementing s**ysUpTime** in MIB-II[mib-II].)

NOTE - **JmTimeStampTC** is defined as an **Integer32** so that it can be used as a value of an attribute, i.e., as a value of the **jmAttributeValueAsInteger** object. The **TimeStamp** textual-convention defined in SMNPv2-TC is defined as an **APPLICATION 3 IMPLICIT INTEGER** tag, not an **Integer32**, so cannot be used in this MIB as one of the values of **jmAttributeValueAsInteger**."
SYNTAX **INTEGER(0..2147483647)**

JmJobSourcePlatformTypeTC ::= TEXTUAL-CONVENTION
STATUS current
DESCRIPTION
"The source platform type that can submit jobs to servers or devices in any of the 3 configurations."
REFERENCE
"This is a type 2 enumeration. See Section 3.6.1.2."
SYNTAX INTEGER {

other(1),		
unknown(2),		
sptUNIX(3),	--	UNIX~~(tm)~~
sptOS2(4),	--	OS/2
sptPCDOS(5),	--	DOS
sptNT(6),	--	NT
sptMVS(7),	--	MVS
sptVM(8),	--	VM
sptOS400(9),	--	OS/400
sptVMS(10),	--	VMS
sptWindows~~95~~(11),	--	Windows~~95~~
sptNetWare(12)	--	NetWare

}

JmFinishingTC ::= TEXTUAL-CONVENTION
STATUS current
DESCRIPTION
"The type of finishing operation.

These values are the same as the enum values of the IPP 'finishings' attribute. See Section 3.6.1.2.

other(1),
Some other finishing operation besides one of the specified or registered values.

unknown(2),
The finishing is unknown.

none(3),
Perform no finishing.

staple(4),
Bind the document(s) with one or more staples. The exact number and placement of the staples is site-defined.

~~**stapleTopLeft(5),**~~
~~Place one or more staples on the top left corner of the document(s).~~

~~**stapleBottomLeft(6),**~~
~~Place one or more staples on the bottom left corner of the document(s).~~

~~**stapleTopRight(7),**~~
~~Place one or more staples on the top right corner of the document(s).~~

~~**stapleBottomRight(8),**~~
~~Place one or more staples on the bottom right corner of the document(s).~~

~~**saddleStitch(9),**~~
~~Bind the document(s) with one or more staples (wire stitches) along the middle fold. The exact number and placement of the stitches is site-defined.~~

~~**edgeStitch(10),**~~
~~Bind the document(s) with one or more staples (wire stitches) along one edge. The exact number and placement of the staples is site-defined.~~

punch(5~~11~~),
This value indicates that holes are required in the finished document. The exact number

and placement of the holes is site-defined The punch specification MAY be satisfied (in a site- and implementation-specific manner) either by drilling/punching, or by substituting pre-drilled media.

cover(612),
This value is specified when it is desired to select a non-printed (or pre-printed) cover for the document. This does not supplant the specification of a printed cover (on cover stock medium) by the document itself.

bind(713)
This value indicates that a binding is to be applied to the document; the type and placement of the binding is product-specific."

```
        REFERENCE
            "This is a type 2 enumeration.  See Section 3.6.1.2."
        SYNTAX      INTEGER {
            other(1),
            unknown(2),
            none(3),
            staple(4),
            staple(5),
            staple(6),
            staple(7),
            staple(8),
            saddle(9),
            edge(10),
            punch(511),
            cover(612),
            bind(713)
        }
```

```
JmPrintQualityTC ::= TEXTUAL-CONVENTION
        STATUS      current
        DESCRIPTION
            "Print quality settings.

            These values are the same as the enum values of the IPP 'print-quality' attribute.  See Section
            3.6.1.2."
        REFERENCE
            "This is a type 2 enumeration.  See Section 3.6.1.2."
        SYNTAX      INTEGER {
              other(1),          --  Not one of the specified or registered values.
                                 --
              unknown(2),        --  The actual value is unknown.
              draft(3),          --  Lowest quality available on the printer.
```

```
            normal(4),      --  Normal or intermediate quality on the printer.
                            --
            high(5)         --  Highest quality available on the printer.
        }


JmPrinterResolutionTC ::= TEXTUAL-CONVENTION
        STATUS      current
        DESCRIPTION
            "Printer resolutions.

            Nine octets consisting of two 4-octet SIGNED-INTEGERs followed by a SIGNED-BYTE.
            The values are the same as those specified in the Printer MIB [printmib]. The first SIGNED-
            INTEGER contains the value of prtMarkerAddressabilityXFeedDir.  The second SIGNED-
            INTEGER contains the value of prtMarkerAddressabilityFeedDir.  The SIGNED-BYTE
            contains the value of prtMarkerAddressabilityUnit.

            Note: the latter value is either 3 (tenThousandsOfInches) or 4 (micrometers) and the
            addressability is in 10,000 units of measure. Thus the SIGNED-INTEGERs represent integral
            values in either dots-per-inch or dots-per-centimeter.

            The syntax is the same as the IPP 'printer-resolution' attribute.  See Section 3.6.1.2."
        SYNTAX      OCTET STRING (SIZE(9))


JmTonerEconomyTC ::= TEXTUAL-CONVENTION
        STATUS      current
        DESCRIPTION
            "Toner economy settings."
        REFERENCE
            "This is a type 2 enumeration.  See Section 3.6.1.2."
        SYNTAX      INTEGER {
            unknown(2),     --  unknown.
            off(3),         --  Off.  Normal.  Use full toner.
            on(4)           --  On.  Use less toner than normal.
        }


JmBooleanTC ::= TEXTUAL-CONVENTION
```

```
        STATUS      current
        DESCRIPTION
                "Boolean true or false value."
        REFERENCE
                "This is a type 2 enumeration.  See Section 3.6.1.2."
        SYNTAX      INTEGER {
                      unknown(2),       --    unknown.
                      false(3),         --    FALSE.
                      true(4)           --    TRUE.
        }


JmMediumTypeTC ::= TEXTUAL-CONVENTION
        STATUS      current
        DESCRIPTION
                "Identifies the type of medium.

                other(1),
                        The type is neither one of the values listed in this specification nor a registered value.

                unknown(2),
                        The type is not known.

                stationery(3),
                        Separately cut sheets of an opaque material.

                transparency(4),
                        Separately cut sheets of a transparent material.

                envelope(5),
                        Envelopes that can be used for conventional mailing purposes.

                envelopePlain(6),
                        Envelopes that are not preprinted and have no windows.

                envelopeWindow(7),
                        Envelopes that have windows for addressing purposes.

                continuousLong(8),
                        Continuously connected sheets of an opaque material connected along the long edge.

                continuousShort(9),
                        Continuously connected sheets of an opaque material connected along the short edge.
```

tabStock(10),
Media with tabs.

multiPartForm(11),
Form medium composed of multiple layers not pre-attached to one another; each sheet MAY be drawn separately from an input source.

labels(12),
Label-stock.

multiLayer(13)
Form medium composed of multiple layers which are pre-attached to one another, e.g. for use with impact printers."

REFERENCE
"This is a type 2 enumeration. See Section 3.6.1.2."
SYNTAX INTEGER {
other(1),
unknown(2),
stationery(3),
transparency(4),
envelope(5),
envelopePlain(6),
envelopeWindow(7),
continuousLong(8),
continuousShort(9),
tabStock(10),
multiPartForm(11),
labels(12),
multiLayer(13)
}

JmJobSubmissionTypeTC ::= TEXTUAL-CONVENTION
STATUS current
DESCRIPTION
"Identifies the format type of a job submission ID.

Each job submission ID is a fixed-length, 48-octet printable US-ASCII [US-ASCII] coded character string containing no control characters, consisting of the following fields:

octet 1 The format letter identifying the format.
_____The US-ASCII characters '0-9', 'A-Z', and 'a-z'
_____are assigned in order giving 62 possible
_____formats.
octets 2-40 A 39-character, US-ASCII trailing SPACE filled

field specified by the format letter, if the
data is less than 39 ASCII characters.
octets 41-48 A sequential or random number to make the ID
quasi-unique.

If the client does not supply a job submission ID in the job submission protocol, then the agentserver SHALL assign a job submission ID using any of the standard formats that are reserved for to the agent. Clients SHALL not use formats that are reserved forto agents and agents SHALL NOT use formats that are reserved for clients, in order to reduce conflicts in ID generation. See the description for which formats are reserved for clients or for agents.

Registration of additional formats may be done following the procedures described in Section 3.6.3.

The format values defined at the time of completion of thise specification are:

Format Letter	Description
'**0**'	octets 2-40: last 39 bytes of the **jmJobOwner** object. octets 41-48: 8-decimal-digit sequential number. This format is reserved forto agents. ~~for use when the client does not supply a job submission ID.~~ NOTE - Clients wishing to use a job submission ID that incorporates the job owner, SHALL use format '8', not format '0'~~, in order to reduce the chances of one client assigning the same ID as the agent when receiving a job from another client that does not supply a job submission id.~~ ~~NOTE - other formats may be registered that are reserved to the agent for use when the client does not supply a job submission ID~~.
'**1**'	octets 2-40: last 39 bytes of the **jobName** attribute. octets 41-48: 8-decimal-digit random number. This format is reserved for clients.
'**2**'	octets 2-40: Client MAC address: in hexadecimal with each nibble of the 6 octet address being '0'-'9' or 'A' - 'F' (uppercase only). Most significant octet first. octets 41-48: 8-decimal-digit sequential number This format is reserved for clients.
'**3**'	octets 2-40: last 39 bytes of the client URL [URI-spec].

octets 41-48: 8-decimal-digit sequential number
This format is reserved for clients.

'**4**' octets 2-40: last 39 bytes of the URI [URI-spec] assigned by the server or device to the job when the job was submitted for processing.
octets 41-48: 8-decimal-digit sequential number
This format is reserved for agents.

'**5**' octets 2-40: last 39 bytes of a user number, such as POSIX user number.
octets 41-48: 8-decimal-digit sequential number
This format is reserved for clients.

'**6**' octets 2-40: last 39 bytes of the user account number.
octets 41-48: 8-decimal-digit sequential number
This format is reserved for clients.

'**7**' octets 2-40: last 39 bytes of the DTMF incoming FAX routing number.
octets 41-48: 8-decimal-digit sequential number
This format is reserved for clients.

'**8**' octets 2-40: last 39 bytes of the job owner name (that the agent returns in the **jmJobOwner** object).
octets 41-48: 8-decimal-digit sequential number
This format is reserved for clients.

'9' octets 2-40: last 39 bytes of the host name with trailing SPACES that submitted the job to this server/device using a protocol, such as LPD [RFC-1179] which includes the host name in the job submission protocol.
octets 41-48: 8-decimal-digit leading zero representation of the job id generated by the by the submitting server (configuration 3) or the client (configuration 1 and 2), such as in the LPD protocol.
This format is reserved for clients.

NOTE - the job submission id is only intended to be unique between a limited set of clients for a limited duration of time, namely, for the life time of the job in the context of the server or device that is processing the job. Some of the formats include something that is unique per client and a random number so that the same job submitted by the same client will have a different job submission id. For other formats, where part of the id is guaranteed to be unique for each client, such as the MAC address or URL, a sequential number SHOULD suffice for each client (and may be easier for each client to manage). Therefore, the length of the job submission id has been selected to reduce the probability of collision to an extremely low number, but is not

intended to be an absolute guarantee of uniqueness. None-the-less, collisions are remotely possible, but without bad consequences, since this MIB is intended to be used only for monitoring jobs, not for controlling and managing them."

REFERENCE

"This is like a type 2 enumeration. See section 3.6.3."

SYNTAX OCTET STRING(SIZE(1)) -- ASCII '0'-'9', 'A'-'Z', 'a'-'z'

JmJobStateTC ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"The current state of the job (**pending**, **processing**, **completed**, etc.).

The following figure shows the normal job state transitions:



Figure 4 - Normal Job State Transitions

Normally a job progresses from left to right. Other state transitions are unlikely, but are not forbidden. Not shown are the transitions to the **canceled** state from the **pending**, **pendingHeld**, ~~**processing**,~~ and **processingStopped** states.

Jobs in the **pending**, **processing**, and **processingStopped** states are called 'active', while jobs in the **pendingHeld**, **canceled**, **aborted**, and **completed** states are called 'inactive'. Jobs reach one of the three terminal states: **completed**, **canceled**, or **aborted,** *after* the jobs have completed all activity, and all MIB objects and attributes have reached their final values for the job.

These values are the same as the enum values of the IPP 'job-state' job attribute. See Section 3.6.1.2.

unknown(2),

The job state is *not* known, or its state is indeterminate.

pending(3),

The job is a candidate to start processing, but is not yet processing.

pendingHeld(4),
The job is not a candidate for processing for any number of reasons but will return to the **pending** state as soon as the reasons are no longer present. The job's **jmJobStateReasons1** object and/or **jobStateReasons*N*** (*N*=2..4) attributes SHALL indicate why the job is no longer a candidate for processing. The reasons are represented as bits in the **jmJobStateReasons1** object and/or **jobStateReasons*N*** (*N*=2..4) attributes. See the **JmJobStateReasons*N*TC** (*N*=1..4) textual convention for the specification of each reason.

processing(5),
One of~~Either~~:

1. the job is using, or is attempting to use, one or more ~~document transforms which include (1)~~ purely software processes that are analyzing, creating, or interpreting a PDL, etc.,~~and (2)~~

2. the job is using, or is attempting to use, one or more hardware devices that are interpreting a PDL, making marks on a medium, and/or performing finishing, such as stapling, etc.,

OR

3~~2~~. (configuration 2) the server has made the job ready for printing, but the output device is not yet printing it, either because the job hasn't reached the output device or because the job is queued in the output device or some other spooler, awaiting the output device to print it.

When the job is in the **processing** state, the entire job state includes the detailed status represented in the device MIB indicated by the **hrDeviceIndex** value of the job's **physicalDevice** attribute, if the agent implements such a device MIB.

Implementations MAY, though they NEED NOT, include additional values in the job's **jmJobStateReasons1** object to indicate the progress of the job, such as adding the **jobPrinting** value to indicate when the device is actually making marks on a medium and/or the **processingToStopPoint** value to indicate that the server or device is in the process of canceling or aborting the job.

processingStopped(6),
The job has stopped while processing for any number of reasons and will return to the **processing** state as soon as the reasons are no longer present.

The job's **jmJobStateReasons1** object and/or the job's **jobStateReasons*N*** (***N*=2..4**) attributes MAY indicate why the job has stopped processing. For example, if the output device is stopped, the **deviceStopped** value MAY be included in the job's **jmJobStateReasons1** object.

NOTE - When an output device is stopped, the device usually indicates its condition in human readable form at the device. The management application can obtain more

complete device status remotely by querying the appropriate device MIB using the job's **deviceIndex** attribute(s), if the agent implements such a device MIB

canceled(7),
A client has canceled the job and ~~the job is either: (1) in the process of being terminated by~~ the server or device ~~or (2)~~ has completed canceling the job *and* all MIB objects and attributes have reached their final values for the job~~terminating~~. While the server or device is canceling the job, the job's **jmJobStateReasons1** object SHOULD contain the **processingToStopPoint** value and one of ~~either~~ the **canceledByUser,** ~~or~~ **canceledByOperator,** or **canceledAtDevice** values. The **canceledByUser**, **canceledByOperator**, or **canceledAtDevice** values remain while the job is in the **canceled** state.

aborted(8),
The job has been aborted by the system, usually while the job was in the **processing** or **processingStopped** state and the server or device has completed aborting the job *and* all MIB objects and attributes have reached their final values for the job. While the server or device is aborting the job, the job's **jmJobStateReasons1** object MAY contain the **processingToStopPoint** and **abortedBySystem** values. If implemented, the **abortedBySystem** value SHALL remain while the job is in the **aborted** state.

completed(9)
The job has completed successfully or with warnings or errors after processing and all of the media have been successfully stacked in the appropriate output bin(s). The job's **jmJobStateReasons1** object SHOULD contain one of: **completedSuccessfully**, **completedWithWarnings**, or **completedWithErrors** values."

```
        REFERENCE
            "This is a type 2 enumeration.  See Section 3.6.1.2."
        SYNTAX      INTEGER {
            unknown(2),
            pending(3),
            pendingHeld(4),
            processing(5),
            processingStopped(6),
            canceled(7),
            aborted(8),
            completed(9)
        }


JmAttributeTypeTC ::= TEXTUAL-CONVENTION
        STATUS      current
        DESCRIPTION
            "The type of the attribute which identifies the attribute.
```

In the following definitions of the enums, each description indicates whether the useful value of the attribute SHALL be represented using the **jmAttributeValueAsInteger** or the

jmAttributeValueAsOctets objects by the initial tag: '**INTEGER:**' or '**OCTETS:**', respectively.

Some attributes allow the agent implementer a choice of useful values of either an integer, an octets representation, or both, depending on implementation. These attributes are indicated with '**INTEGER:**' AND/OR '**OCTETS:**' tags.

A very few attributes require both objects at the same time to represent a pair of useful values (see **mediumConsumed(171)**). These attributes are indicated with '**INTEGER:**' AND '**OCTETS:**' tags. See the **jmAttributeGroup** for the descriptions of these two MANDATORY objects.

NOTE - The enum assignments are grouped logically with values assigned in groups of 20, so that additional values may be registered in the future and assigned a value that is part of their logical grouping.

Values in the range 2**30 to 2**31-1 are reserved for private or experimental usage. This range corresponds to the same range reserved in IPP. Implementers are warned that use of such values may conflict with other implementations. Implementers are encouraged to request registration of enum values following the procedures in Section 3.6.1.

NOTE: No attribute name exceeds 31 characters.

The standard attribute types defined at the time of completion of the specification are:

jmAttributeTypeIndex	**Datatype**
other(1),	**Integer32(-2..2147483647) AND/OR OCTET STRING(SIZE(0..63))**

INTEGER: and/or OCTETS: An attribute that is not in the list and/or that has not been approved and registered with IANA.

```
++++++++++++++++++++++++++++++++++++++++++++++++++++++++++++++++
+ Job State attributes
+
+ The following attributes specify the state of a job.
++++++++++++++++++++++++++++++++++++++++++++++++++++++++++++++++
```

jobStateReasons2(3), **JmJobStateReasons2TC**

INTEGER: Additional information about the job's current state that augments the **jmJobState** object. See the description under the **JmJobStateReasons1TC** textual-convention.

jobStateReasons3(4), **JmJobStateReasons3TC**

INTEGER: Additional information about the job's current state that augments the

jmJobState object. See the description under **JmJobStateReasons1TC** textual-convention.

jobStateReasons4(5), JmJobStateReasons4TC
INTEGER: Additional information about the job's current state that augments the **jmJobState** object. See the description under **JmJobStateReasons1TC** textual-convention.

processingMessage(6), JmUTF8StringTC(SIZE(0..63))
OCTETS: MULTI-ROW: A coded character set message that is generated by the server or device during the processing of the job as a simple form of processing log to show progress and any problems.

There is no restriction for the same message occurring in multiple rows.

jobCodedCharSet(7), CodedCharSet
INTEGER: The MIBenum identifier of the coded character set that the agent is using to represent coded character set objects and attributes of type '**JmJobStringTC**'. These coded character set objects and attributes are either: (1) supplied by the job submitting client or (2) defaulted by the server or device when omitted by the job submitting client. The agent SHALL represent these objects and attributes in the MIB either (1) in the coded character set as they were submitted or (2) MAY convert the coded character set to another coded character set or encoding scheme as identified by the **jobCodedCharSet** attribute.

These MIBenum values are assigned by IANA [IANA-charsets] when the coded character sets are registered. The coded character set SHALL be one of the ones registered with IANA [IANA] and the enum value uses the **CodedCharSet** textual-convention from the Printer MIB. See the **JmJobStringTC** textual-convention.

If the agent does not know what coded character set was used by the job submitting client, the agent SHALL either (1) return the '**unknown(2)**' value for the **jobCodedCharSet** attribute or (2) not return the **jobCodedCharSet** attribute for the job. See Section 3.5.2, entitled 'Text generated by the job submitter'.

++
+ Job Identification attributes
+
+ The following attributes help an end user, a system
+ operator, or an accounting program identify a job.
++

jobURI(20), OCTET STRING(SIZE(1..255))
OCTETS: The job's Universal Resource Identifier (URI) [RFC-1738]. See IPP for example usage.

NOTE - The agent may be able to generate this value on each SNMP Get operation from smaller values, rather than having to store the entire URI.

If the URI exceeds 255 octets, the agent SHALL truncate from the beginning (since the end tends to be more unique than the beginning).

jobAccountName(21), **OCTET STRING~~JmJobStringTC~~(SIZE(0..63))**

OCTETS: Arbitrary binary information which MAY be coded character set data or encrypted data supplied by the submitting user for use by accounting services to allocate or categorize charges for services provided, such as a customer account name or number.

NOTE: This attribute NEED NOT be printable characters.

serverAssignedJobName(22), **JmJobStringTC(SIZE(0..63))**

OCTETS: Configuration 3 only: The human readable string name, number, or ID of the job as assigned by the server that submitted the job to the device that the agent is providing access to with this MIB.

NOTE - This attribute is intended for enabling a user to find his/her job that a server submitted to a device when either the client does not support the **jmJobSubmissionID** or the server does not pass the **jmJobSubmissionID** through to the device.

jobName(23), **JmJobStringTC(SIZE(0..63))**

OCTETS: The human readable string name of the job as assigned by the submitting user to help the user distinguish between his/her various jobs. This name does not need to be unique.

This attribute is intended for enabling a user or the user's application to convey a job name that MAY be printed on a start sheet, returned in a **query** result, or used in notification or logging messages.

In order to assist users to find their jobs for job submission protocols that don't supply a **jmJobSubmissionID**, the agent SHOULD maintain the **jobName** attribute for the time specified by the **jmGeneralJobPersistence** object, rather than the (shorter) **jmGeneralAttributePersistence** object.

If this attribute is not specified when the job is submitted, no job name is assumed, but implementation specific defaults are allowed, such as the value of the **documentName** attribute of the first document in the job or the **fileName** attribute of the first document in the job.

The **jobName** attribute is distinguished from the **jobComment** attribute, in that the **jobName** attribute is intended to permit the submitting user to distinguish between different jobs that he/she has submitted. The **jobComment** attribute is intended to be free form additional information that a user might wish to use to communicate with himself/herself, such as a reminder of what to do with the results or to indicate a different set of input parameters were tried in several different job submissions.

jobServiceTypes(24), **JmJobServiceTypesTC**

INTEGER: Specifies the type(s) of service to which the job has been submitted (print, fax, scan, etc.). The service type is bit encoded with each job service type so that more general and arbitrary services can be created, such as services with more than one destination type, or ones with only a source or only a destination. For example, a job service might **scan**, **faxOut**, and **print** a single job. In this case, three bits would be set in the **jobServiceTypes** attribute, corresponding to the hexadecimal values: **0x8** + **0x20** + **0x4**, respectively, yielding: **0x2C**.

Whether this attribute is set from a job attribute supplied by the job submission client or is set by the recipient job submission server or device depends on the job submission protocol. This attribute SHALL be implemented if the server or device has other types in addition to or instead of printing.

One of the purposes of this attribute is to permit a requester to filter out jobs that are not of interest. For example, a printer operator may only be interested in jobs that include printing.

jobSourceChannelIndex(25), Integer32(0..2147483647)

INTEGER: The index of the row in the associated Printer MIB[print-mib] of the channel which is the source of the print job.

jobSourcePlatformType(26), **JmJobSourcePlatformTypeTC**

INTEGER: The source platform type of the immediate upstream submitter that submitted the job to the server (configuration 2) or device (configuration 1 and 3) to which the agent is providing access. For configuration 1, this is the type of the client that submitted the job to the device; for configuration 2, this is the type of the client that submitted the job to the server; and for configuration 3, this is the type of the server that submitted the job to the device.

submittingServerName(27), **JmJobStringTC(SIZE(0..63))**

OCTETS: For configuration 3 only: The administrative name of the server that submitted the job to the device.

submittingApplicationName(28), **JmJobStringTC(SIZE(0..63))**

OCTETS: The name of the client application (not the server in configuration 3) that submitted the job to the server or device.

jobOriginatingHost(29), **JmJobStringTC(SIZE(0..63))**

OCTETS: The name of the client host (not the server host name in configuration 3) that submitted the job to the server or device.

deviceNameRequested(30), **JmJobStringTC(SIZE(0..63))**

OCTETS: The administratively defined coded character set name of the target device requested by the submitting user. For configuration 1, its value corresponds to the Printer MIB[print-mib]: **prtGeneralPrinterName** object. For configuration 2 and 3, its value is the name of the logical or physical device that the user supplied to indicate to the server on which device(s) they wanted the job to be processed.

queueNameRequested(31), **JmJobStringTC(SIZE(0..63))**

OCTETS: The administratively defined coded character set name of the target queue requested by the submitting user. For configuration 1, its value corresponds to the queue in the device for which the agent is providing access. For configuration 2 and 3, its value is the name of the queue that the user supplied to indicate to the server on which device(s) they wanted the job to be processed.

NOTE - typically an implementation SHOULD support either the **deviceNameRequested** or **queueNameRequested** attribute, but not both.

physicalDevice(32), **hrDeviceIndex**
AND/OR
JmUTF8StringTC(SIZE(0..63))

INTEGER: MULTI-ROW: The index of the physical device MIB instance requested/used, such as the Printer MIB[print-mib]. This value is an **hrDeviceIndex** value. See the Host Resources MIB[hr-mib].

AND/OR

OCTETS: MULTI-ROW: The name of the physical device to which the job is assigned.

numberOfDocuments(33), **Integer32(-2..2147483647)**

INTEGER: The number of documents in this job.

fileName(34), **JmJobStringTC(SIZE(0..63))**

OCTETS: MULTI-ROW: The coded character set file name or URI[URI-spec] of the document.

There is no restriction on the same file name occurring in multiple rows.

documentName(35), **JmJobStringTC(SIZE(0..63))**

OCTETS: MULTI-ROW: The coded character set name of the document.

There is no restriction on the same document name occurring in multiple rows.

jobComment(36), **JmJobStringTC(SIZE(0..63))**

OCTETS: An arbitrary human-readable coded character text string supplied by the submitting user or the job submitting application program for any purpose. For example, a user might indicate what he/she is going to do with the printed output or the job submitting application program might indicate how the document was produced.

The **jobComment** attribute is not intended to be a name; see the **jobName** attribute.

documentFormatIndex(37), **Integer32(0..2147483647)**

INTEGER: MULTI-ROW: The index in the **prtInterpreterTable** in the Printer MIB[print-mib] of the page description language (PDL) or control language interpreter that this job requires/uses. A document or a job MAY use more than one PDL or control language.

NOTE - As with all intensive attributes where multiple rows are allowed, there SHALL be only one distinct row for each distinct interpreter; there SHALL be no duplicates.

NOTE - This attribute type is intended to be used with an agent that implements the Printer MIB and SHALL not be used if the agent does not implement the Printer MIB. Such an agent SHALL use the **documentFormat** attribute instead.

documentFormat(38), **PrtInterpreterLangFamilyTC**
AND/OR
OCTET STRING(SIZE(0..63))

INTEGER: MULTI-ROW: The interpreter language family corresponding to the Printer MIB[print-mib] **prtInterpreterLangFamily** object, that this job requires/uses. A document or a job MAY use more than one PDL or control language.

AND/OR

OCTETS: MULTI-ROW: The document format registered as a media type[iana-media-types], i.e., the name of the MIME content-type/subtype. Examples: 'application/postscript', 'application/vnd.hp-PCL', and 'application/pdf'

++
+ Job Parameter attributes
+
+ The following attributes represent input parameters
+ supplied by the submitting client in the job submission
+ protocol.
++

jobPriority(50), **Integer32(1..100)**

INTEGER: The priority for scheduling the job. It is used by servers and devices that employ a priority-based scheduling algorithm.

A higher value specifies a higher priority. The value **1** is defined to indicate the lowest possible priority (a job which a priority-based scheduling algorithm SHALL pass over in favor of higher priority jobs). The value **100** is defined to indicate the highest possible priority. Priority is expected to be evenly or 'normally' distributed across this range. The mapping of vendor-defined priority over this range is implementation-specific.

jobProcessAfterDateAndTime(51), **DateAndTime** (SNMPv2-TC)

OCTETS: The calendar date and time of day after which the job SHALL become a candidate to be scheduled for processing. If the value of this attribute is in the future, the server SHALL set the value of the job's **jmJobState** object to **pendingHeld** and add the **jobProcessAfterSpecified** bit value to the job's **jmJobStateReasons1** object. When the specified date and time arrives, the server SHALL remove the **jobProcessAfterSpecified** bit value from the job's **jmJobStateReasons1** object and, if no other reasons remain, SHALL change the job's **jmJobState** object to **pending**.

jobHold(52), **JmBooleanTC**

INTEGER: If the value is '**true(4)**', a client has explicitly specified that the job is to be held until explicitly released. Until the job is explicitly released by a client, the job SHALL be in the **pendingHeld** state with the **jobHoldSpecified** value in the **jmJobStateReasons1** attribute.

jobHoldUntil(53), **JmJobStringTC(SIZE(0..63))**

OCTETS: The named time period during which the job SHALL become a candidate for processing, such as '**evening**', '**night**', '**weekend**', '**second-shift**', '**third-shift**', etc., as defined by the system administrator. See IPP [ipp-model] for the standard keyword values. Until that time period arrives, the job SHALL be in the **pendingHeld** state with the **jobHoldUntilSpecified** value in the **jmJobStateReasons1** object. The value '**no-hold**' SHALL indicate explicitly that no time period has been specified; the absence of this attribute SHALL indicate implicitly that no time period has been specified.

outputBin(54), **Integer32(0..2147483647)**
AND/OR
JmJobStringTC(SIZE(0..63))

INTEGER: MULTI-ROW: The output subunit index in the Printer MIB[print-mib]

AND/OR

OCTETS: the name or number (represented as ASCII digits) of the output bin to which all or part of the job is placed in.

sides(55), **Integer32(-2..2)**

INTEGER: MULTI-ROW: The number of sides, '**1**' or '**2**', that any document in this job requires/used.

finishing(56), **JmFinishingTC**

INTEGER: MULTI-ROW: Type of finishing that any document in this job requires/used.

++

+ Image Quality attributes (requested and consumed)

+

+ For devices that can vary the image quality.

++

printQualityRequested(70), **JmPrintQualityTC**

INTEGER: MULTI-ROW: The print quality selection requested for a document in the job for printers that allow quality differentiation.

printQualityUsed(71), **JmPrintQualityTC**

INTEGER: MULTI-ROW: The print quality selection actually used by a document in the job for printers that allow quality differentiation.

printerResolutionRequested(72), JmPrinterResolutionTC
OCTETS: MULTI-ROW: The printer resolution requested for a document in the job for printers that support resolution selection.

printerResolutionUsed(73), JmPrinterResolutionTC
OCTETS: MULTI-ROW: The printer resolution actually used by a document in the job for printers that support resolution selection.

tonerEcomonyRequested(74), JmTonerEconomyTC
INTEGER: MULTI-ROW: The toner economy selection requested for documents in the job for printers that allow toner economy differentiation.

tonerEcomonyUsed(75), JmTonerEconomyTC
INTEGER: MULTI-ROW: The toner economy selection actually used by documents in the job for printers that allow toner economy differentiation.

tonerDensityRequested(76), Integer32(-2..100)
INTEGER: MULTI-ROW: The toner density requested for a document in this job for devices that can vary toner density levels. Level 1 is the lowest density and level 100 is the highest density level. Devices with a smaller range, SHALL map the 1-100 range evenly onto the implemented range.

tonerDensityUsed(77), Integer32(-2..100)
INTEGER: MULTI-ROW: The toner density used by documents in this job for devices that can vary toner density levels. Level 1 is the lowest density and level 100 is the highest density level. Devices with a smaller range, SHALL map the 1-100 range evenly onto the implemented range.

++
+ Job Progress attributes (requested and consumed)
+
+ Pairs of these attributes can be used by monitoring
+ applications to show an indication of relative progress
+ to users.
++

jobCopiesRequested(90), Integer32(-2..2147483647)
INTEGER: The number of copies of the entire job that are to be produced.

jobCopiesCompleted(91), Integer32(-2..2147483647)
INTEGER: The number of copies of the entire job that have been completed so far.

documentCopiesRequested(92), Integer32(-2..2147483647)
INTEGER: The total count of the number of document copies requested for the job as a whole. If there are documents A, B, and C, and document B is specified to produce 4 copies, the number of document copies requested is 6 for the job.

This attribute SHALL be used only when a job has multiple documents. The **jobCopiesRequested** attribute SHALL be used when the job has only one document.

documentCopiesCompleted(93), Integer32(-2..2147483647)

INTEGER: The total count of the number of document copies completed so far for the job as a whole. If there are documents A, B, and C, and document B is specified to produce **4** copies, the number of document copies starts a **0** and runs up to **6** for the job as the job processes.

This attribute SHALL be used only when a job has multiple documents. The **jobCopiesCompleted** attribute SHALL be used when the job has only one document.

jobKOctetsTransferred(94), Integer32(-2..2147483647)

INTEGER: The number of K (1024) octets transferred to the server or device to which the agent is providing access. This count is independent of the number of copies of the job or documents that will be produced, but it is only a measure of the number of bytes transferred to the server or device.

The agent SHALL round the actual number of octets transferred up to the next higher K. Thus **0** octets SHALL be represented as '**0**', 1-1024 octets SHALL BE represented as '**1**', 1025-2048 SHALL be '**2**', etc. When the job completes, the values of the **jmJobKOctetsRequested** object and the **jobKOctetsTransferred** attribute SHALL be equal.

NOTE - The **jobKOctetsTransferred** can be used with the **jmJobKOctetsRequested** object in order to produce a relative indication of the progress of the job for agents that do not implement the **jmJobKOctetsProcessed** object.

++
+ Impression attributes
+
+ For a print job, an impression is the marking of the
+ entire side of a sheet. Two-sided processing involves two
+ impressions per sheet. Two-up is the placement of two
+ logical pages on one side of a sheet and so is still a
+ single impression. See also jmJobImpressionsRequested and
+ jmJobImpressionsCompleted objects in the jmJobTable.
++

impressionsSpooled(110), Integer32(-2..2147483647)

INTEGER: The number of impressions spooled to the server or device for the job so far.

impressionsSentToDevice(111), Integer32(-2..2147483647)

INTEGER: The number of impressions sent to the device for the job so far.

impressionsInterpreted(112), Integer32(-2..2147483647)

INTEGER: The number of impressions interpreted for the job so far.

impressionsCompletedCurrentCopy(113), Integer32(-2..2147483647)

INTEGER: The number of impressions completed by the device for the current copy of the current document so far. For printing, the impressions completed includes interpreting, marking, and stacking the output. For other types of job services, the number of impressions completed includes the number of impressions processed.

This value SHALL be reset to **0** for each document in the job and for each document copy.

fullColorImpressionsCompleted(114), Integer32(-2..2147483647)

INTEGER: The number of full color impressions completed by the device for this job so far. For printing, the impressions completed includes interpreting, marking, and stacking the output. For other types of job services, the number of impressions completed includes the number of impressions processed. Full color impressions are typically defined as those requiring 3 or more colorants, but this MAY vary by implementation.

highlightColorImpressionsCompleted(115), Integer32(-2..2147483647)

INTEGER: The number of highlight color impressions completed by the device for this job so far. For printing, the impressions completed includes interpreting, marking, and stacking the output. For other types of job services, the number of impressions completed includes the number of impressions processed. Highlight color impressions are typically defined as those requiring black plus one other colorant, but this MAY vary by implementation.

++
+ Page attributes
+
+ A page is a logical page. Number up can impose more than
+ one page on a single side of a sheet. Two-up is the
+ placement of two logical pages on one side of a sheet so
+ that each side counts as two pages.
++

pagesRequested(130), Integer32(-2..2147483647)

INTEGER: The number of logical pages requested by the job to be processed.

pagesCompleted(131), Integer32(-2..2147483647)

INTEGER: The number of logical pages completed for this job so far.

For implementations where multiple copies are produced by the interpreter with only a single pass over the data, the final value SHALL be equal to the value of the **pagesRequested** object. For implementations where multiple copies are produced by the interpreter by processing the data for each copy, the final value SHALL be a multiple of the value of the **pagesRequested** object.

NOTE - See the **impressionsCompletedCurrentCopy** and **pagesCompletedCurrentCopy** attributes for attributes that are reset on each document copy.

NOTE - The **pagesCompleted** object can be used with the p**agesRequested** object to provide an indication of the relative progress of the job, provided that the multiplicative factor is taken into account for some implementations of multiple copies.

pagesCompletedCurrentCopy(132), Integer32(-2..2147483647)

INTEGER: The number of logical pages completed for the current copy of the document so far. This value SHALL be reset to **0** for each document in the job and for each document copy.

++
+ Sheet attributes
+
+ The sheet is a single piece of a medium, whether printing
+ on one or both sides.
++

sheetsRequested(150), Integer32(-2..2147483647)

INTEGER: The number of medium sheets requested to be processed for this job.

sheetsCompleted(151), Integer32(-2..2147483647)

INTEGER: The number of medium sheets that have completed marking and stacking for the entire job so far whether those sheets have been processed on one side or on both.

sheetsCompletedCurrentCopy(152), Integer32(-2..2147483647)

INTEGER: The number of medium sheets that have completed marking and stacking for the current copy of a document in the job so far whether those sheets have been processed on one side or on both.

The value of this attribute SHALL be reset to **0** as each document in the job starts being processed and for each document copy as it starts being processed.

++
+ Resources attributes (requested and consumed)
+
+ Pairs of these attributes can be used by monitoring
+ applications to show an indication of relative usage to
+ users.
++

mediumRequested(170), JmMediumTypeTC
AND/OR
JmJobStringTC(SIZE(0..63))

INTEGER: MULTI-ROW: The type

AND/OR
OCTETS: the name of the medium that is required by the job.

mediumConsumed(171), **Integer32(-2..2147483647)**
AND
JmJobStringTC(SIZE(0..63))
INTEGER: The number of sheets
AND
OCTETS: MULTI-ROW: the name of the medium that has been consumed so far whether those sheets have been processed on one side or on both.

This attribute SHALL have both **Integer32** and **OCTET STRING** (represented as **JmJobStringTC)** values.

colorantRequested(172), **Integer32(-2..2147483647)**
AND/OR
JmJobStringTC(SIZE(0..63))
INTEGER: MULTI-ROW: The index (**prtMarkerColorantIndex**) in the Printer MIB[print-mib]
AND/OR
OCTETS: the name of the colorant requested.

colorantConsumed(173), **Integer32(-2..2147483647)**
AND/OR
JmJobStringTC(SIZE(0..63))
INTEGER: MULTI-ROW: The index (**prtMarkerColorantIndex**) in the Printer MIB[print-mib]
AND/OR
OCTETS: the name of the colorant consumed.

++
+ Time attributes (set by server or device)
+
+ This section of attributes are ones that are set by the
+ server or device that accepts jobs. Two forms of time are
+ provided. Each form is represented in a separate attribute.
+ See section 3.1.2 and section 3.1.3 for the
+ conformance requirements for time attribute for agents and
+ monitoring applications, respectively. The two forms are:
+
+ 'DateAndTime' is an 8 or 11 octet binary encoded year,
+ month, day, hour, minute, second, deci-second with
+ optional offset from UTC. See SNMPv2-TC [SMIv2-TC].
+
+ NOTE: 'DateAndTime' is not printable characters; it is
+ binary.
+
+ 'JmTimeStampTC' is the time of day measured in the number of

+ seconds since the system was booted.
++

jobSubmissionToServerTime(190), **JmTimeStampTC**
AND/OR
DateAndTime

INTEGER: Configuration 3 only: The time
AND/OR
OCTETS: the date and time that the job was submitted to the server (as distinguished from the device which uses jobSubmissionTime).

jobSubmissionTime(191), **JmTimeStampTC**
AND/OR
DateAndTime

INTEGER: Configurations 1, 2, and 3: The time
AND/OR
OCTETS: the date and time that the job was submitted to the server or device to which the agent is providing access.

jobStartedBeingHeldTime(192), **JmTimeStampTC**
AND/OR
DateAndTime

INTEGER: The time
AND/OR
OCTETS: the date and time that the job last entered the **pendingHeld** state. If the job has never entered the **pendingHeld** state, then the value SHALL be '0' or the attribute SHALL not be present in the table.

jobStartedProcessingTime(193), **JmTimeStampTC**
AND/OR
DateAndTime

INTEGER: The time
AND/OR
OCTETS: the date and time that the job started processing.

jobCompletion~~ed~~Time(194), **JmTimeStampTC**
AND/OR
DateAndTime

INTEGER: The time
AND/OR
OCTETS: the date and time that the job entered the **completed**, **canceled**, or **aborted** state.

jobProcessingCPUTime(195) **Integer32(-2..2147483647)**
UNITS 'seconds'
INTEGER: The amount of CPU time in seconds that the job has been in the **processing** state. If the job enters the **processingStopped** state, that elapsed time SHALL not be

included. In other words, the **jobProcessingCPUTime** value SHOULD be relatively repeatable when the same job is processed again on the same device."

REFERENCE
"See Section 3.2 entitled 'The Attribute Mechanism' for a description of this textual-convention and its use in the **jmAttributeTable**.

This is a type 2 enumeration. See Section 3.6.1.2."
SYNTAX INTEGER {
other(1),
unknown(2),
jobStateReasons2(3),
jobStateReasons3(4),
jobStateReasons4(5),
processingMessage(6),
jobCodedCharSet(7),

jobURI(20),
jobAccountName(21),
serverAssignedJobName(22),
jobName(23),
jobServiceTypes(24),
jobSourceChannelIndex(25),
jobSourcePlatformType(26),
submittingServerName(27),
submittingApplicationName(28),
jobOriginatingHost(29),
deviceNameRequested(30),
queueNameRequested(31),
physicalDevice(32),
numberOfDocuments(33),
fileName(34),
documentName(35),
jobComment(36),
documentFormatIndex(37),
documentFormat(38),

jobPriority(50),
jobProcessAfterDateAndTime(51),
jobHold(52),
jobHoldUntil(53),
outputBin(54),
sides(55),
finishing(56),

printQualityRequested(70),
printQualityUsed(71),
printerResolutionRequested(72),
printerResolutionUsed(73),

```
            tonerEcomonyRequested(74),
            tonerEcomonyUsed(75),
            tonerDensityRequested(76),
            tonerDensityUsed(77),

            jobCopiesRequested(90),
            jobCopiesCompleted(91),
            documentCopiesRequested(92),
            documentCopiesCompleted(93),
            jobKOctetsTransferred(94),

            impressionsSpooled(110),
            impressionsSentToDevice(111),
            impressionsInterpreted(112),
            impressionsCompletedCurrentCopy(113),
            fullColorImpressionsCompleted(114),
            highlightColorImpressionsCompleted(115),

            pagesRequested(130),
            pagesCompleted(131),
            pagesCompletedCurrentCopy(132),

            sheetsRequested(150),
            sheetsCompleted(151),
            sheetsCompletedCurrentCopy(152),

            mediumRequested(170),
            mediumConsumed(171),
            colorantRequested(172),
            colorantConsumed(173),

            jobSubmissionToServerTime(190),
            jobSubmissionTime(191),
            jobStartedBeingHeldTime(192),
            jobStartedProcessingTime(193),
            jobCompletionedTime(194),
            jobProcessingCPUTime(195)
        }


JmJobServiceTypesTC ::= TEXTUAL-CONVENTION
        STATUS      current
        DESCRIPTION
            "Specifies the type(s) of service to which the job has been submitted (print, fax, scan, etc.).  The
            service type is represented as an enum that is bit encoded with each job service type so that
            more general and arbitrary services can be created, such as services with more than one
```

destination type, or ones with only a source or only a destination. For example, a job service might **scan**, **faxOut**, and **print** a single job. In this case, three bits would be set in the **jobServiceTypes** attribute, corresponding to the hexadecimal values: **0x8** + **0x20** + 0**x**4, respectively, yielding: **0x2C**.

Whether this attribute is set from a job attribute supplied by the job submission client or is set by the recipient job submission server or device depends on the job submission protocol. With either implementation, the agent SHALL return a non-zero value for this attribute indicating the type of the job.

One of the purposes of this attribute is to permit a requester to filter out jobs that are not of interest. For example, a printer operator MAY only be interested in jobs that include printing. That is why the attribute is in the job identification category.

The following service component types are defined (in hexadecimal) and are assigned a separate bit value for use with the **jobServiceTypes** attribute:

other 0x1
The job contains some instructions that are not one of the identified types.

unknown 0x2
The job contains some instructions whose type is unknown to the agent.

print 0x4
The job contains some instructions that specify printing

scan 0x8
The job contains some instructions that specify scanning

faxIn 0x10
The job contains some instructions that specify receive fax

faxOut 0x20
The job contains some instructions that specify sending fax

getFile 0x40
The job contains some instructions that specify accessing files or documents

putFile 0x80
The job contains some instructions that specify storing files or documents

mailList 0x100
The job contains some instructions that specify distribution of documents using an electronic mail system."

REFERENCE
"These bit definitions are the equivalent of a type 2 enum except that combinations of them MAY be used together. See section 3.6.1.2."
SYNTAX **INTEGER(0..2147483647)** -- 31 bits, all but sign bit

JmJobStateReasons1TC ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"The **JmJobStateReasons*N*TC** (***N***=**1..4**) textual-conventions are used with the **jmJobStateReasons1** object and **jobStateReasonsN** (***N***=2..4), respectively, to provide additional information regarding the current **jmJobState** object value. These values MAY be used with any job state or states for which the reason makes sense.

NOTE - While values cannot be added to the **jmJobState** object without impacting deployed clients that take actions upon receiving **jmJobState** values, it is the intent that additional **JmJobStateReasons*N*TC** enums can be defined and registered without impacting such deployed clients. In other words, the **jmJobStateReasons1** object and **jobStateReasons*N*** attributes are intended to be extensible.

NOTE - The Job Monitoring MIB contains a superset of the IPP values[ipp-model] for the IPP 'job-state-reasons' attribute, since the Job Monitoring MIB is intended to cover other job submission protocols as well. Also some of the names of the reasons have been changed from 'printer' to 'device', since the Job Monitoring MIB is intended to cover additional types of devices, including input devices, such as scanners.

The following standard values are defined (in hexadecimal) as *powers of two,* since multiple values MAY be used at the same time. For ease of understanding, the **JmJobStateReasons1TC** reasons are presented in the order in which the reasons are likely to occur (if implemented), starting with the **'jobIncoming'** value and ending with the **'jobCompletedWithErrors'** value.

other **0x1**

The job state reason is not one of the standardized or registered reasons.

unknown **0x2**

The job state reason is not known to the agent or is indeterminent.

jobIncoming **0x4**

The job has been accepted by the server or device, but the server or device is expecting (1) additional operations from the client to finish creating the job and/or (2) is accessing/accepting document data.

submissionInterrupted **0x8**

The job was not completely submitted for some unforeseen reason, such as: (1) the server has crashed before the job was closed by the client, (2) the server or the document transfer method has crashed in some non-recoverable way before the document data was entirely

transferred to the server, (3) the client crashed or failed to close the job before the time-out period.

jobOutgoing **0x108**

Configuration 2 only: The server is transmitting the job to the device.

jobHoldSpecified **0x2010**

The value of the job's jobHold(52) attribute is TRUE. The job SHALL NOT be a candidate for processing until this reason is removed and there are no other reasons to hold the job.

jobHoldUntilSpecified **0x4020**

The value of the job's jobHoldUntil(53) attribute specifies a time period that is still in the future. The job SHALL NOT be a candidate for processing until this reason is removed and there are no other reasons to hold the job.

jobProcessAfterSpecified **0x8040**

The value of the job's jobProcessAfterDateAndTime(51) attribute specifies a time that is still in the future. The job SHALL NOT be a candidate for processing until this reason is removed and there are no other reasons to hold the job.

resourcesAreNotReady **0x10080**

At least one of the resources needed by the job, such as media, fonts, resource objects, etc., is not ready on any of the physical devices for which the job is a candidate. This condition MAY be detected when the job is accepted, or subsequently while the job is **pending** or **processing**, depending on implementation.

deviceStoppedPartly **0x200100**

One or more, but not all, of the devices to which the job is assigned are stopped. If all of the devices are stopped (or the only device is stopped), the **deviceStopped** reason SHALL be used.

deviceStopped **0x400200**

The device(s) to which the job is assigned is (are all) stopped.

jobInterpreting **0x800**

The device to which the job is assigned is interpreting the document data.

jobPrinting **0x1000400**

The output device to which the job is assigned is marking media. This attribute is useful for servers and output devices which spend a great deal of time processing (1) when no marking is happening and then want to show that marking is now happening or (2) when the job is in the process of being canceled or aborted while the job remains in the **processing** state, but the marking has not yet stopped so that impression or sheet counts are still increasing for the job.

jobCanceledByUser **0x2000800**

The job was canceled by the owner of the jobuser, i.e., by an unknown user or by a user

whose name is the same as the value of the job's **jmJobOwner** object, or by some other authorized end-user, such as a member of the job owner's security group.

jobCanceledByOperator **0x41000**

The job was canceled by the operator, i.e., by a user who has been authenticated as having operator privileges (whether local or remote)whose name is different than the value of the job's **jmJobOwner** object.

jobCanceledAtDevice **0x8000**

The job was canceled by an unidentified local user, i.e., a user at a console at the device.

abortedBySystem **0x100002000**

The job (1) is in the process of being aborted, (2) has beenwas aborted by the system and placed in the **'aborted'** state, or (3) has been aborted by the system and placed .

NOTE - When the system puts a job into the **'aborted'** job state, this reason is not needed. This reason is needed only when the system aborts a job, but, instead of placing the job in the **aborted** job state, places the job in the '**pendingHeld'** state, so that a user or operator can manually try the job again.

processingToStopPoint **0x200004000**

The requester has issued an operation to cancel or interrupt the job or the server/device has aborted the job, but the server/device is still performing some actions on the job until a specified stop point occurs or job termination/cleanup is completed.

This reason is recommended to be used in conjunction with the **processingcanceled or aborted** job state to indicate that the server/device is still performing some actions on the job whileafter the job remains inleaves the **processing** state. After all the , so that some of the job's resources consumed counters may have stopped still be incrementing, the server/device moves the job from the **processing** state to while the job is in the **canceled** or **aborted** job states.

serviceOffLine **0x40000**

The service or document transform is off-line and accepting no jobs. All **pending** jobs are put into the **pendingHeld** state. This situation could be true if the service's or document transform's input is impaired or broken.

jobCompletedSuccessfully **0x80000**

The job completed successfully.

jobCompletedWithWarnings **0x100000**

The job completed with warnings.

jobCompletedWithErrors **0x200000**

The job completed with errors (and possibly warnings too).

The following additional job state reasons have been added to represent job states that are in ISO DPA[iso-dpa] and other job submission protocols:

jobPaused **0x400000**
The job has been indefinitely suspended by a client issuing an operation to suspend the job so that other jobs may proceed using the same devices. The client MAY issue an operation to resume the paused job at any time, in which case the agent SHALL remove the **jobPaused** values from the job's **jmJobStateReasons1** object and the job is eventually resumed at or near the point where the job was paused.

jobInterrupted **0x800000**
The job has been interrupted while processing by a client issuing an operation that specifies another job to be run instead of the current job. The server or device will automatically resume the interrupted job when the interrupting job completes.

jobRetained **0x1000000**
The job is being retained by the server or device with all of the job's document data (and submitted resources, such as fonts, logos, and forms, if any). Thus a client could issue an operation to the server or device to either (1) re-do the job (or a copy of the job) on the same server or device or (2) resubmit the job to another server or device. When a client could no longer re-do/resubmit the job, such as after the document data has been discarded, the agent SHALL remove the **jobRetained** value from the **jmJobStateReasons1** object."

REFERENCE
"These bit definitions are the equivalent of a type 2 enum except that combinations of bits may be used together. See section 3.6.1.2. The remaining bits are reserved for future standardization and/or registration."

SYNTAX **INTEGER(0..2147483647)** -- 31 bits, all but sign bit

JmJobStateReasons2TC ::= TEXTUAL-CONVENTION
STATUS current
DESCRIPTION
"This textual-convention is used with the **jobStateReasons2** attribute to provides additional information regarding the **jmJobState** object. See the description under **JmJobStateReasons1TC** for additional information that applies to all reasons.

The following standard values are defined (in hexadecimal) as *powers of two,* since multiple values may be used at the same time:

cascaded **0x1**
An outbound gateway has transmitted all of the job's job and document attributes and data to another spooling system.

deletedByAdministrator **0x2**
The administrator has deleted the job.

discardTimeArrived **0x4**

The job has been deleted due to the fact that the time specified by the job's job-discard-time attribute has arrived.

postProcessingFailed **0x8**

The post-processing agent failed while trying to log accounting attributes for the job; therefore the job has been placed into the completed state with the **jobRetained** **jmJobStateReasons1** object value for a system-defined period of time, so the administrator can examine it, resubmit it, etc.

jobTransforming **0x10**

The server/device is interpreting document data and producing another electronic representation.

~~**submissionInterrupted** **0x10**~~

~~Indicates that the job was not completely submitted for some unforeseen reason, such as: (1) the server has crashed before the job was closed by the client, (2) the server or the document transfer method has crashed in some non-recoverable way before the document data was entirely transferred to the server, (3) the client crashed or failed to close the job before the time-out period.~~

maxJobFaultCountExceeded **0x20**

The job has faulted several times and has exceeded the administratively defined fault count limit.

devicesNeedAttentionTimeOut **0x40**

One or more document transforms that the job is using needs human intervention in order for the job to make progress, but the human intervention did not occur within the site-settable time-out value.

needsKeyOperatorTimeOut **0x80**

One or more devices or document transforms that the job is using need a specially trained operator (who may need a key to unlock the device and gain access) in order for the job to make progress, but the key operator intervention did not occur within the site-settable time-out value.

jobStartWaitTimeOut **0x100**

The server/device has stopped the job at the beginning of processing to await human action, such as installing a special cartridge or special non-standard media, but the job was not resumed within the site-settable time-out value and the server/device has transitioned the job to the **pendingHeld** state.

jobEndWaitTimeOut **0x200**

The server/device has stopped the job at the end of processing to await human action, such as removing a special cartridge or restoring standard media, but the job was not resumed within the site-settable time-out value and the server/device has transitioned the job to the completed state.

jobPasswordWaitTimeOut **0x400**

The server/device has stopped the job at the beginning of processing to await input of the job's password, but the password was not received within the site-settable time-out value.

deviceTimedOut **0x800**

A device that the job was using has not responded in a period specified by the device's site-settable attribute.

connectingToDeviceTimeOut **0x1000**

The server is attempting to connect to one or more devices which may be dial-up, polled, or queued, and so may be busy with traffic from other systems, but server was unable to connect to the device within the site-settable time-out value.

transferring **0x2000**

The job is being transferred to a down stream server or downstream device.

queuedInDevice **0x4000**

The server/device has ~~job has been~~ queued the job in a down stream server or downstream device.

jobQueued **0x8000**

The server/device has queued the document data.

jobCleanup **0x108000**

The server/device is performing cleanup activity as part of ending normal processing.

jobPasswordWait **0x20000**

The server/device has selected the job to be next to process, but instead of assigning resources and starting the job processing, the server/device has transitioned the job to the **pendingHeld** state to await entry of a password (and dispatched another job, if there is one).

validating **0x40000**

The server/device is validating the job *after* accepting the job.

queueHeld **0x80000**

The operator has held the entire job set or queue.

jobProofWait **0x100000**

The job has produced a single proof copy and is in the **pendingHeld** state waiting for the requester to issue an operation to release the job to print normally, obeying any job and document copy attributes that were originally submitted.

heldForDiagnostics **0x200000**

The system is running intrusive diagnostics, so that all jobs are being held.

~~**serviceOffLine** **0x400000**~~

~~The service/document transform is off-line and accepting no jobs. All pending jobs are put into the pendingHeld state. This could be true if its input is impaired or broken.~~

noSpaceOnServer **0x800000**
There is no room on the server to store all of the job.

pinRequired **0x1000000**
The System Administrator settable device policy is (1) to require PINs, and (2) to hold jobs that do not have a pin supplied as an input parameter when the job was created.

exceededAccountLimit **0x2000000**
The account for which this job is drawn has exceeded its limit. This condition SHOULD be detected before the job is scheduled so that the user does not wait until his/her job is scheduled only to find that the account is overdrawn. This condition MAY also occur while the job is processing either as processing begins or part way through processing.

heldForRetry **0x4000000**
The job encountered some errors that the server/device could not recover from with its normal retry procedures, but the error might not be encountered if the job is processed again in the future. Example cases are phone number busy or remote file system in-accessible. For such a situation, the server/device SHALL transition the job from the **processing** to the **pendingHeld**, rather than to the **aborted** state.

The following values are from the X/Open PSIS draft standard:

canceledByShutdown **0x8000000**
The job was canceled because the server or device was shutdown before completing the job.

deviceUnavailable **0x10000000**
This job was aborted by the system because the device is currently unable to accept jobs.

wrongDevice **0x20000000**
This job was aborted by the system because the device is unable to handle this particular job; the spooler SHOULD try another device or the user should submit the job to another device.

badJob **0x40000000**
This job was aborted by the system because this job has a major problem, such as an ill-formed PDL; the spooler SHOULD not even try another device. "

REFERENCE
"These bit definitions are the equivalent of a type 2 enum except that combinations of them may be used together. See section 3.6.1.2. See the description under **JmJobStateReasons1TC** and the **jobStateReasons2** attribute."

SYNTAX **INTEGER(0..2147483647)** -- 31 bits, all but sign bit

JmJobStateReasons3TC ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"This textual-convention is used with the **jobStateReasons3** attribute to provides additional information regarding the **jmJobState** object. See the description under **JmJobStateReasons1TC** for additional information that applies to all reasons.

The following standard values are defined (in hexadecimal) as *powers of two,* since multiple values may be used at the same time:

jobInterruptedByDeviceFailure 0x1

A device or the print system software that the job was using has failed while the job was processing. The server or device is keeping the job in the **pendingHeld** state until an operator can determine what to do with the job."

REFERENCE

"These bit definitions are the equivalent of a type 2 enum except that combinations of them may be used together. See section 3.6.1.2. The remaining bits are reserved for future standardization and/or registration. See the description under **JmJobStateReasons1TC** and the **jobStateReasons3** attribute."

SYNTAX **INTEGER(0..2147483647)** -- 31 bits, all but sign bit

JmJobStateReasons4TC ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"This textual-convention is used in the **jobStateReasons4** attribute to provides additional information regarding the **jmJobState** object. See the description under **JmJobStateReasons1TC** for additional information that applies to all reasons.

The following standard values are defined (in hexadecimal) as *powers of two,* since multiple values may be used at the same time:

none yet defined. These bits are reserved for future standardization and/or registration."

REFERENCE

"These bit definitions are the equivalent of a type 2 enum except that combinations of them may be used together. See section 3.6.1.2. See the description under **JmJobStateReasons1TC** and the **jobStateReasons4** attribute."

SYNTAX **INTEGER(0..2147483647)** -- 31 bits, all but sign bit

```
2718
2719  jobmonMIBObjects  OBJECT IDENTIFIER  ::= { jobmonMIB 1 }
2720
2721  -- The General Group (MANDATORY)
2722
2723  -- The jmGeneralGroup consists entirely of the jmGeneralTable.
2724
2725  jmGeneral  OBJECT IDENTIFIER ::= { jobmonMIBObjects 1 }
2726
2727  jmGeneralTable  OBJECT-TYPE
2728      SYNTAX      SEQUENCE OF JmGeneralEntry
2729      MAX-ACCESS  not-accessible
2730      STATUS      current
2731      DESCRIPTION
2732          "The jmGeneralTable consists of information of a general nature that are per-job-set, but are
2733          not per-job.  See Section 2 entitled 'Terminology and Job Model' for the definition of a job set."
2734      REFERENCE
2735          "The MANDATORY-GROUP macro specifies that this group is MANDATORY."
2736      ::= { jmGeneral 1 }
2737
2738  jmGeneralEntry  OBJECT-TYPE
2739      SYNTAX      JmGeneralEntry
2740      MAX-ACCESS  not-accessible
2741      STATUS      current
2742      DESCRIPTION
2743          "Information about a job set (queue).
2744
2745          An entry SHALL exist in this table for each job set."
2746      INDEX  { jmGeneralJobSetIndex }
2747      ::= { jmGeneralTable 1 }
2748
2749  JmGeneralEntry ::= SEQUENCE {
2750      jmGeneralJobSetIndex                    Integer32(1..32767),
2751      jmGeneralNumberOfActiveJobs             Integer32(0..2147483647),
2752      jmGeneralOldestActiveJobIndex           Integer32(0..2147483647),
2753      jmGeneralNewestActiveJobIndex           Integer32(0..2147483647),
2754      jmGeneralJobPersistence                 Integer32(15..2147483647),
2755      jmGeneralAttributePersistence           Integer32(15..2147483647),
2756      jmGeneralJobSetName                     JmUTF8StringTC(SIZE(0..63))
2757  }
2758
2759  jmGeneralJobSetIndex OBJECT-TYPE
2760      SYNTAX      Integer32(1..32767)
2761      MAX-ACCESS  not-accessible
2762      STATUS      current
2763      DESCRIPTION
2764          "A unique value for each job set in this MIB.  The jmJobTable and jmAttributeTable tables
2765          have this same index as their primary index.
2766
```

The value(s) of the **jmGeneralJobSetIndex** SHALL be persistent across power cycles, so that clients that have retained **jmGeneralJobSetIndex** values will access the same job sets upon subsequent power-up.

An implementation that has only one job set, such as a printer with a single queue, SHALL hard code this object with the value **1**."

REFERENCE

"See Section 2 entitled 'Terminology and Job Model' for the definition of a job set. Corresponds to the first index in **jmJobTable** and **jmAttributeTable**."

::= { jmGeneralEntry 1 }

jmGeneralNumberOfActiveJobs OBJECT-TYPE

SYNTAX **Integer32(0..2147483647)**

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The current number of 'active' jobs in the **jmJobIDTable, jmJobTable,** and **jmAttributeTable**, i.e., the total number of jobs that are in the **pending**, **processing**, or **processingStopped** states. See the **JmJobStateTC** textual-convention for the exact specification of the semantics of the job states."

::= { jmGeneralEntry 2 }

jmGeneralOldestActiveJobIndex OBJECT-TYPE

SYNTAX Integer32 (0..2147483647)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The **jmJobIndex** of the oldest job that is still in one of the 'active' states (**pending**, **processing**, or **processingStopped)**. In other words, the index of the 'active' job that has been in the job tables the longest.

If there are no active jobs, the agent SHALL set the value of this object to **0**."

REFERENCE

"See Section 3.2 entitled 'The Job Tables and the Oldest Active and Newest Active Indexes' for a description of the usage of this object."

::= { jmGeneralEntry 3 }

jmGeneralNewestActiveJobIndex OBJECT-TYPE

SYNTAX Integer32 (0..2147483647)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The **jmJobIndex** of the newest job that is in one of the 'active' states (**pending**, **processing**, or **processingStopped)**. In other words, the index of the 'active' job that has been most recently added to the **job tables.**

When all jobs become 'inactive', i.e., enter the **pendingHeld**, **completed**, **canceled,** or **aborted** states, the agent SHALL set the value of this object to **0**."

REFERENCE

"See Section 3.2 entitled 'The Job Tables and the Oldest Active and Newest Active Indexes' for a description of the usage of this object."
::= { jmGeneralEntry 4 }

jmGeneralJobPersistence OBJECT-TYPE
SYNTAX **Integer32(15..2147483647)**
UNITS "seconds"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The minimum time in seconds for this instance of the Job Set that an entry SHALL remain in the **jmJobIDTable** and **jmJobTable** after **processing** has *completed,* i.e., the minimum time in seconds starting when the job enters the **completed**, **canceled, or aborted** state.

Configuring this object is implementation-dependent.~~Depending on implementation, the value of this object MAY be either: (1) set by the system administrator by means outside this specification or (2) fixed by the implementation.~~

This value SHALL be equal to or greater than the value of **jmGeneralAttributePersistence**. This value SHOULD be at least 60 which gives a monitoring application one minute in which to poll for job data."
DEFVAL { 60 } -- one minute
::= { jmGeneralEntry 5 }

jmGeneralAttributePersistence OBJECT-TYPE
SYNTAX **Integer32(15..2147483647)**
UNITS "seconds"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The minimum time in seconds for this instance of the Job Set that an entry SHALL remain in the **jmAttributeTable** after **processing** has *completed* , i.e., the time in seconds starting when the job enters the **completed**, **canceled,** or **aborted** state.

Configuring this object is implementation-dependent.~~Depending on implementation, the value of this object MAY be either (1) set by the system administrator by means outside this specification or MAY be (2) fixed by the implementation.~~

This value SHOULD be at least 60 which gives a monitoring application one minute in which to poll for job data."
DEFVAL { 60 } -- one minute
::= { jmGeneralEntry 6 }

jmGeneralJobSetName OBJECT-TYPE
SYNTAX **JmUTF8StringTC(SIZE(0..63))**
MAX-ACCESS read-only
STATUS current
DESCRIPTION

```
                "The human readable name of this job set assigned by the system administrator (by means
                outside of this MIB).  Typically, this name SHOULD be the name of the job queue.  If a server
                or device has only a single job set, this object can be the administratively assigned name of the
                server or device itself.  This name does not need to be unique, though each job set in a single
                Job Monitoring MIB SHOULD have distinct names.

                NOTE - The purpose of this object is to help the user of the job monitoring application
                distinguish between several job sets in implementations that support more than one job set."
        REFERENCE
                "See the OBJECT compliance macro for the minimum maximum length required for
                conformance."
        ::= { jmGeneralEntry 7 }



-- The Job ID Group (MANDATORY)

-- The jmJobIDGroup consists entirely of the jmJobIDTable.

jmJobID  OBJECT IDENTIFIER ::= { jobmonMIBObjects 2 }

jmJobIDTable  OBJECT-TYPE
        SYNTAX      SEQUENCE OF JmJobIDEntry
        MAX-ACCESS  not-accessible
        STATUS      current
        DESCRIPTION
                "The jmJobIDTable provides a correspondence map (1) between the job submission ID that a
                client uses to refer to a job and (2) the jmGeneralJobSetIndex and jmJobIndex that the Job
                Monitoring MIB agent assigned to the job and that are used to access the job in all of the other
                tables in the MIB.  If a monitoring application already knows the jmGeneralJobSetIndex and
                the jmJobIndex of the job it is querying, that application NEED NOT use the jmJobIDTable."
        REFERENCE
                "The MANDATORY-GROUP macro specifies that this group is MANDATORY."
        ::= { jmJobID 1 }

jmJobIDEntry  OBJECT-TYPE
        SYNTAX      JmJobIDEntry
        MAX-ACCESS  not-accessible
        STATUS      current
        DESCRIPTION
                "The map from (1) the jmJobSubmissionID to (2) the jmGeneralJobSetIndex and
                jmJobIndex.

                An entry SHALL exist in this table for each job currently known to the agent for all job sets and
                job states.  Each job SHALL appear in one and only one job set."
        INDEX  { jmJobSubmissionID }
        ::= { jmJobIDTable 1 }
```

```
JmJobIDEntry ::= SEQUENCE {
        jmJobSubmissionID                       OCTET STRING(SIZE(48)),
        jmJobIDJobSetIndex                      Integer32(1..32767),
        jmJobIDJobIndex                         Integer32(1..2147483647)
}

jmJobSubmissionID OBJECT-TYPE
        SYNTAX      OCTET STRING(SIZE(48))
        MAX-ACCESS  not-accessible
        STATUS      current
        DESCRIPTION
                "A quasi-unique 48-octet fixed-length string ID which identifies the job within a particular
                client-server environment.  There are multiple formats for the jmJobSubmissionID.  Each
                format SHALL be uniquely identified.  See the JmJobSubmissionIDTypeTC textual convention.
                Each format SHALL be registered using the procedures of a type 2 enum.  See section 3.6.3
                entitled: 'IANA Registration of Job Submission Id Formats'.

                If the requester (client or server) does not supply a job submission ID in the job submission
                protocol, then the recipient (server or device) SHALL assign a job submission ID using any of
                the standard formats that have been reserved for~~to~~ agents and adding the final 8 octets to
                distinguish the ID from others submitted from the same requester.

                The monitoring application, whether in the client or running separately, MAY use the job
                submission ID to help identify which jmJobIndex was assigned by the agent, i.e., in which row
                the job information is in the other tables.

                NOTE - fixed-length is used so that a management application can use a shortened GetNext
                varbind (in SNMPv1 and SNMPv2) in order to get the next submission ID, disregarding the
                remainder of the ID in order to access jobs independent of the trailing identifier part, e.g., to get
                all jobs submitted by a particular jmJobOwner or submitted from a particular MAC address."
        REFERENCE
                "See the JmJobSubmissionIDTypeTC textual convention.
                See APPENDIX B - Support of the Job Submission ID in Job Submission Protocols."
        ::= { jmJobIDEntry 1 }

jmJobIDJobSetIndex OBJECT-TYPE
        SYNTAX      Integer32(1..32767)
        MAX-ACCESS  read-only
        STATUS      current
        DESCRIPTION
                "This object contains the value of the jmGeneralJobSetIndex for the job with the
                jmJobSubmissionID value, i.e., the job set index of the job set in which the job was placed
                when that server or device accepted the job.  This 16-bit value in combination with the
                jmJobIDJobIndex value permits the management application to access the other tables to
                obtain the job-specific objects for this job."
        REFERENCE
                "See jmGeneralJobSetIndex in the jmGeneralTable."
        ::= { jmJobIDEntry 2 }
```

```
2962
2963    jmJobIDJobIndex OBJECT-TYPE
2964            SYNTAX      Integer32(1..2147483647)
2965            MAX-ACCESS  read-only
2966            STATUS      current
2967            DESCRIPTION
2968                    "This object contains the value of the jmJobIndex for the job with the jmJobSubmissionID
2969                    value, i.e., the job index for the job when the server or device accepted the job.  This value, in
2970                    combination with the jmJobIDJobSetIndex value, permits the management application to
2971                    access the other tables to obtain the job-specific objects for this job."
2972            REFERENCE
2973                    "See jmJobIndex in the jmJobTable."
2974            ::= { jmJobIDEntry 3 }
2975
2976
2977
2978
2979    -- The Job Group (MANDATORY)
2980
2981    -- The jmJobGroup consists entirely of the jmJobTable.
2982
2983    jmJob  OBJECT IDENTIFIER ::= { jobmonMIBObjects 3 }
2984
2985    jmJobTable  OBJECT-TYPE
2986            SYNTAX      SEQUENCE OF JmJobEntry
2987            MAX-ACCESS  not-accessible
2988            STATUS      current
2989            DESCRIPTION
2990                    "The jmJobTable consists of basic job state and status information for each job in a job set that
2991                    (1) monitoring applications need to be able to access in a single SNMP Get operation, (2) that
2992                    have a single value per job, and (3) that SHALL always be implemented."
2993            REFERENCE
2994                    "The MANDATORY-GROUP macro specifies that this group is MANDATORY."
2995            ::= { jmJob 1 }
2996
2997    jmJobEntry  OBJECT-TYPE
2998            SYNTAX      JmJobEntry
2999            MAX-ACCESS  not-accessible
3000            STATUS      current
3001            DESCRIPTION
3002                    "Basic per-job state and status information.
3003
3004                    An entry SHALL exist in this table for each job, no matter what the state of the job is.  Each job
3005                    SHALL appear in one and only one job set."
3006            REFERENCE
3007                    "See Section 3.2 entitled 'The Job Tables'."
3008            INDEX  { jmGeneralJobSetIndex, jmJobIndex }
3009            ::= { jmJobTable 1 }
3010
```

```
JmJobEntry ::= SEQUENCE {
        jmJobIndex                          Integer32(1..2147483647),
        jmJobState                          JmJobStateTC,
        jmJobStateReasons1                  JmJobStateReasons1TC,
        jmNumberOfInterveningJobs           Integer32(-2..2147483647),
        jmJobKOctetsRequested               Integer32(-2..2147483647),
        jmJobKOctetsProcessed               Integer32(-2..2147483647),
        jmJobImpressionsRequested           Integer32(-2..2147483647),
        jmJobImpressionsCompleted           Integer32(-2..2147483647),
        jmJobOwner                          JmJobStringTC(SIZE(0..63))
}

jmJobIndex OBJECT-TYPE
        SYNTAX      Integer32(1..2147483647)
        MAX-ACCESS  not-accessible
        STATUS      current
        DESCRIPTION
                "The sequential, monatonically increasing identifier index for the job generated by the server or
                device when that server or device accepted the job.  This index value permits the management
                application to access the other tables to obtain the job-specific row entries."
        REFERENCE
                "See Section 3.2 entitled 'The Job Tables and the Oldest Active and Newest Active Indexes'.
                See Section 3.4 entitled 'Job Identification'.
                See also jmGeneralNewestActiveJobIndex for the largest value of jmJobIndex.
                See JmJobSubmissionTypeTC for a limit on the size of this index if the agent represents it as
                an 8-digit decimal number."
        ::= { jmJobEntry 1 }

jmJobState OBJECT-TYPE
        SYNTAX      JmJobStateTC
        MAX-ACCESS  read-only
        STATUS      current
        DESCRIPTION
                "The current state of the job (pending, processing, completed, etc.).  Agents SHALL
                implement only those states which are appropriate for the particular implementation.  However,
                management applications SHALL be prepared to receive all the standard job states.

                The final value for this object SHALL be one of: completed, canceled, or aborted.  The
                minimum length of time that the agent SHALL maintain MIB data for a job in the completed,
                canceled, or aborted state before removing the job data from the jmJobIDTable and
                jmJobTable is specified by the value of the jmGeneralJobPersistence object."
        ::= { jmJobEntry 2 }

jmJobStateReasons1 OBJECT-TYPE
        SYNTAX      JmJobStateReasons1TC
        MAX-ACCESS  read-only
        STATUS      current
        DESCRIPTION
```

"Additional information about the job's current state, i.e., information that augments the value of the job's **jmJobState** object.

Implementation of any reason values is OPTIONAL, but an agent SHOULD return any reason information available These values MAY be used with any job state or states for which the reason makes sense. Since the Job State Reasons will be more dynamic than the Job State, it is recommended that a job monitoring application read this object every time **jmJobState** is read.~~Furthermore, when implemented as with any MIB data, the agent SHALL return these values when the reason applies and SHALL NOT return them when the reason no longer applies whether the value of the job's **jmJobState** object changed or not.~~ When the agent cannot provide a reason for the current state of the job, the ~~agent SHALL set~~ the value of the **jmJobStateReasons1** object and **jobStateReasons*N*** attributes SHALL be~~to~~ **0**."

REFERENCE

"The **jobStateReasons*N*** (***N***=**2..4**) attributes provide further additional information about the job's current state."

::= { jmJobEntry 3 }

jmNumberOfInterveningJobs OBJECT-TYPE

SYNTAX **Integer32(-2..2147483647)**

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of jobs that are expected to complete ~~being~~ processinged ***before*** this job has completed ~~being~~ processinged according to the implementation's queuing algorithm, if no other jobs were to be submitted. In other words, this value is the job's queue position. The agent SHALL return a value of **0** for this attribute when the job is the next job to complete processing (or has completed processing)."

::= { jmJobEntry 4 }

jmJobKOctetsRequested OBJECT-TYPE

SYNTAX **Integer32(-2..2147483647)**

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total size in K (1024) octets of the document(s) being requested to be processed in the job. The agent SHALL round the actual number of octets up to the next highest K. Thus 0 octets SHALL be represented as '**0**', 1-1024 octets SHALL be represented as '**1**', 1025-2048 SHALL be represented as '**2**', etc.

In computing this value, the server/device SHALL *not* include the multiplicative factors contributed by (1) the number of document copies, and (2) the number of job copies, independent of whether the device can process multiple copies of the job or document without making multiple passes over the job or document data and independent of whether the output is collated or not. Thus the server/device computation is independent of the implementation."

::= { jmJobEntry 5 }

jmJobKOctetsProcessed OBJECT-TYPE

SYNTAX **Integer32(-2..2147483647)**

MAX-ACCESS read-only

STATUS current
DESCRIPTION
"The current number of octets processed by the server or device measured in units of K (1024) octets. The agent SHALL round the actual number of octets processed up to the next higher K. Thus 0 octets SHALL be represented as '**0**', 1-1024 octets SHALL be represented as '**1**', 1025-2048 octets SHALL be '**2**', etc. For printing devices, this value is the number interpreted by the page description language interpreter rather than what has been marked on media.

For implementations where multiple copies are produced by the interpreter with only a single pass over the data, the final value SHALL be equal to the value of the **jmJobKOctetsRequested** object. For implementations where multiple copies are produced by the interpreter by processing the data for each copy, the final value SHALL be a multiple of the value of the **jmJobKOctetsRequested** object.

NOTE - See the **impressionsCompletedCurrentCopy** and **pagesCompletedCurrentCopy** attributes for attributes that are reset on each document copy.

NOTE - The **jmJobKOctetsProcessed** object can be used with the **jmJobKOctetsRequested** object to provide an indication of the relative progress of the job, provided that the multiplicative factor is taken into account for some implementations of multiple copies."
::= { jmJobEntry 6 }

jmJobImpressionsRequested OBJECT-TYPE
SYNTAX **Integer32(-2..2147483647)**
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The total size in number of impressions of the document(s) being requested by this job to produce.

In computing this value, the server/device SHALL *not* include the multiplicative factors contributed by (1) the number of document copies, and (2) the number of job copies, independent of whether the device can process multiple copies of the job or document without making multiple passes over the job or document data and independent of whether the output is collated or not. Thus the server/device computation is independent of the implementation."
::= { jmJobEntry 7 }

jmJobImpressionsCompleted OBJECT-TYPE
SYNTAX **Integer32(-2..2147483647)**
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The current number of impressions completed for this job so far. For printing devices, the impressions completed includes interpreting, marking, and stacking the output. For other types of job services, the number of impressions completed includes the number of impressions processed.

For implementations where multiple copies are produced by the interpreter with only a single pass over the data, the final value SHALL be equal to the value of the

jmJobImpressionsRequested object. For implementations where multiple copies are produced by the interpreter by processing the data for each copy, the final value SHALL be a multiple of the value of the **jmJobImpressionsRequested** object.

NOTE - See the **impressionsCompletedCurrentCopy** and **pagesCompletedCurrentCopy** attributes for attributes that are reset on each document copy.

NOTE - The **jmJobImpressionsCompleted** object can be used with the **jmJobImpressionsRequested** object to provide an indication of the relative progress of the job, provided that the multiplicative factor is taken into account for some implementations of multiple copies."

::= { jmJobEntry 8 }

jmJobOwner OBJECT-TYPE
SYNTAX **JmJobStringTC(SIZE(0..63))**
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The coded character set name of the user that submitted the job. The method of assigning this user name will be system and/or site specific but the method MUST insure that the name is unique to the network that is visible to the client and target device.

This value SHOULD be the *authenticated* name of the user submitting the job."
REFERENCE
"See the OBJECT compliance macro for the minimum maximum length required for conformance."
::= { jmJobEntry 9 }

-- The Attribute Group (MANDATORY)

-- The **jmAttributeGroup** consists entirely of the **jmAttributeTable.**
--
-- Implementation of the two objects in this group is MANDATORY.
-- See Section 3.1 entitled 'Conformance Considerations'.
-- An agent SHALL implement any attribute if (1) the server or device
-- supports the functionality represented by the attribute and (2) the
-- information is available to the agent.

jmAttribute OBJECT IDENTIFIER ::= { jobmonMIBObjects 4 }

jmAttributeTable OBJECT-TYPE
SYNTAX SEQUENCE OF JmAttributeEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

```
3205            "The jmAttributeTable SHALL contain attributes of the job and document(s) for each job in a
3206            job set.  Instead of allocating distinct objects for each attribute, each attribute is represented as a
3207            separate row in the jmAttributeTable."
3208        REFERENCE
3209            "The MANDATORY-GROUP macro specifies that this group is MANDATORY.  An agent
3210            SHALL implement any attribute if (1) the server or device supports the functionality represented
3211            by the attribute and (2) the information is available to the agent. "
3212        ::= { jmAttribute 1 }
3213
3214    jmAttributeEntry  OBJECT-TYPE
3215        SYNTAX      JmAttributeEntry
3216        MAX-ACCESS  not-accessible
3217        STATUS      current
3218        DESCRIPTION
3219            "Attributes representing information about the job and document(s) or resources required and/or
3220            consumed.
3221
3222            Each entry in the jmAttributeTable is a per-job entry with an extra index for each type of
3223            attribute (jmAttributeTypeIndex) that a job can have and an additional index
3224            (jmAttributeInstanceIndex) for those attributes that can have multiple instances per job.  The
3225            jmAttributeTypeIndex object SHALL contain an enum type that indicates the type of attribute
3226            (see the JmAttributeTypeTC textual-convention).  The value of the attribute SHALL be
3227            represented in either the jmAttributeValueAsInteger or jmAttributeValueAsOctets objects,
3228            and/or both, as specified in the JmAttributeTypeTC textual-convention.
3229
3230            The agent SHALL create rows in the jmAttributeTable as the server or device is able to
3231            discover the attributes either from the job submission protocol itself or from the document PDL.
3232            As the documents are interpreted, the interpreter MAY discover additional attributes and so the
3233            agent adds additional rows to this table.  As the attributes that represent resources are actually
3234            consumed, the usage counter contained in the jmAttributeValueAsInteger object is
3235            incremented according to the units indicated in the description of the JmAttributeTypeTC
3236            enum.
3237
3238            The agent SHALL maintain each row in the jmJobTable for at least the minimum time after a
3239            job completes as specified by the jmGeneralAttributePersistence object.
3240
3241            Zero or more entries SHALL exist in this table for each job in a job set."
3242        REFERENCE
3243            "See Section 3.3 entitled 'The Attribute Mechanism' for a description of the jmAttributeTable."
3244        INDEX  { jmGeneralJobSetIndex, jmJobIndex, jmAttributeTypeIndex,
3245        jmAttributeInstanceIndex }
3246        ::= { jmAttributeTable 1 }
3247
3248    JmAttributeEntry ::= SEQUENCE {
3249        jmAttributeTypeIndex                JmAttributeTypeTC,
3250        jmAttributeInstanceIndex            Integer32(1..32767),
3251        jmAttributeValueAsInteger           Integer32(-2..2147483647),
3252        jmAttributeValueAsOctets            OCTET STRING(SIZE(0..63))
3253    }
```

jmAttributeTypeIndex OBJECT-TYPE
SYNTAX **JmAttributeTypeTC**
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"The type of attribute that this row entry represents.

The type MAY identify information about the job or document(s) or MAY identify a resource required to process the job before the job start processing and/or consumed by the job as the job is processed.

Examples of job attributes (i.e., apply to the job as a whole) that have only one instance per job include: **jobCopiesRequested(90)**, **documentCopiesRequested(92)**, **jobCopiesCompleted(91)**, **documentCopiesCompleted(93)**, while examples of job attributes that may have more than one instance per job include: **documentFormatIndex(37)**, and **documentFormat(38)**.

Examples of document attributes (one instance per document) include: **fileName(34)**, and **documentName(35)**.

Examples of required and consumed resource attributes include: **pagesRequested(130)**, **mediumRequested(170)**, **pagesCompleted(131)**, and **mediumConsumed(171),** respectively."
::= { jmAttributeEntry 1 }

jmAttributeInstanceIndex OBJECT-TYPE
SYNTAX **Integer32(1..32767)**
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"A running 16-bit index of the attributes of the same type for each job. For those attributes with only a single instance per job, this index value SHALL be **1**. For those attributes that are a single value per document, the index value SHALL be the document number, starting with **1** for the first document in the job. Jobs with only a single document SHALL use the index value of **1**. For those attributes that can have multiple values per job or per document, such as **documentFormatIndex(37)** or **documentFormat(38)**, the index SHALL be a running index for the job as a whole, starting at **1**."
::= { jmAttributeEntry 2 }

jmAttributeValueAsInteger OBJECT-TYPE
SYNTAX **Integer32(-2..2147483647)**
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The integer value of the attribute. The value of the attribute SHALL be represented as an integer if the enum description in the **JmAttributeTypeTC** textual-convention definition has the tag: 'INTEGER:'.

Depending on the enum definition, this object value MAY be an integer, a counter, an index, or an enum, depending on the **jmAttributeTypeIndex** value. The units of this value are specified in the enum description.

For those attributes that are accumulating job consumption as the job is processed as specified in the **JmAttributeTypeTC** textual-convention, SHALL contain the final value after the job completes processing, i.e., this value SHALL indicate the total usage of this resource made by the job.

A monitoring application is able to copy this value to a suitable longer term storage for later processing as part of an accounting system.

Since the agent MAY add attributes representing resources to this table while the job is waiting to be processed or being processed, which can be a long time before any of the resources are actually used, the agent SHALL set the value of the **jmAttributeValueAsInteger** object to **0** for resources that the job has not yet consumed.

Attributes for which the concept of an integer value is meaningless, such as **fileName(34)**, **jobName,** and **processingMessage,** do *not* have the 'INTEGER:' tag in the **JmAttributeTypeTC** definition and so an agent SHALL always return a value of '**-1**' to indicate '**other**' for the value of the **jmAttributeValueAsInteger** object for these attributes.

For attributes which do have the 'INTEGER:' tag in the **JmAttributeTypeTC** definition, if the integer value is not (yet) known, the agent either (1) SHALL not materialize the row in the **jmAttributeTable** until the value is known or (2) SHALL return a '**-2**' to represent an 'unknown' counting integer value, a '**0**' to represent an 'unknown' index value, and a **'2'** to represent an 'unknown(2)' enum value."

::= { jmAttributeEntry 3 }

jmAttributeValueAsOctets OBJECT-TYPE
SYNTAX **OCTET STRING(SIZE(0..63))**
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The octet string value of the attribute. The value of the attribute SHALL be represented as an OCTET STRING if the enum description in the **JmAttributeTypeTC** textual-convention definition has the tag: 'OCTETS:'.

Depending on the enum definition, this object value MAY be a coded character set string (text), such as '**JmUTF8StringTC**', or a binary octet string, such as '**DateAndTime**'.

Attributes for which the concept of an octet string value is meaningless, such as **pagesCompleted**, do *not* have the tag 'OCTETS:' in the **JmAttributeTypeTC** definition and so the agent SHALL always return a zero length string for the value of the **jmAttributeValueAsOctets** object.

For attributes which do have the 'OCTETS:' tag in the **JmAttributeTypeTC** definition, if the OCTET STRING value is not (yet) known, the agent either SHALL not materialize the row in the **jmAttributeTable** until the value is known or SHALL return a zero-length string."

```
3351            ::= { jmAttributeEntry 4 }
3352
```

```
-- Notifications and Trapping
-- Reserved for the future

jobmonMIBNotifications  OBJECT IDENTIFIER  ::= { jobmonMIB 2}



-- Conformance Information

jmMIBConformance OBJECT IDENTIFIER ::= { jobmonMIB 3 }

-- compliance statements
jmMIBCompliance MODULE-COMPLIANCE
        STATUS  current
        DESCRIPTION
                "The compliance statement for agents that implement the
                job monitoring MIB."
        MODULE -- this module
        MANDATORY-GROUPS {
                jmGeneralGroup, jmJobIDGroup, jmJobGroup, jmAttributeGroup }

        OBJECT   jmGeneralJobSetName
        SYNTAX   JmUTF8StringTC (SIZE(0..8))
        DESCRIPTION
                "Only 8 octets maximum string length NEED be supported by the agent."

        OBJECT   jmJobOwner
        SYNTAX   JmJobStringTC (SIZE(0..16))
        DESCRIPTION
                "Only 16 octets maximum string length NEED be supported by the agent."

-- There are no CONDITIONALLY MANDATORY or OPTIONAL groups.

        ::= { jmMIBConformance 1 }

jmMIBGroups     OBJECT IDENTIFIER ::= { jmMIBConformance 2 }

jmGeneralGroup OBJECT-GROUP
        OBJECTS {
                jmGeneralNumberOfActiveJobs,   jmGeneralOldestActiveJobIndex,
                jmGeneralNewestActiveJobIndex, jmGeneralJobPersistence,
                jmGeneralAttributePersistence, jmGeneralJobSetName}
        STATUS  current
        DESCRIPTION
                "The general group."
        ::= { jmMIBGroups 1 }

jmJobIDGroup OBJECT-GROUP
        OBJECTS {
```

```
3402            jmJobIDJobSetIndex, jmJobIDJobIndex }
3403        STATUS  current
3404        DESCRIPTION
3405            "The job ID group."
3406        ::= { jmMIBGroups 2 }
3407
3408    jmJobGroup OBJECT-GROUP
3409        OBJECTS {
3410            jmJobState, jmJobStateReasons1, jmNumberOfInterveningJobs,
3411            jmJobKOctetsRequested, jmJobKOctetsProcessed, jmJobImpressionsRequested,
3412            jmJobImpressionsCompleted, jmJobOwner }
3413        STATUS  current
3414        DESCRIPTION
3415            "The job group."
3416        ::= { jmMIBGroups 3 }
3417
3418    jmAttributeGroup OBJECT-GROUP
3419        OBJECTS {
3420            jmAttributeValueAsInteger, jmAttributeValueAsOctets }
3421        STATUS  current
3422        DESCRIPTION
3423            "The attribute group."
3424        ::= { jmMIBGroups 4 }
3425
3426
3427    END
```

5. Appendix A - Implementing the Job Life Cycle

The job object has well-defined states and client operations that affect the transition between the job states. Internal server and device actions also affect the transitions of the job between the job states. These states and transitions are referred to as the job's *life cycle*.

Not all implementations of job submission protocols have all of the states of the job model specified here. The job model specified here is intended to be a superset of most implementations. It is the purpose of the agent to map the particular implementation's job life cycle onto the one specified here. The agent MAY omit any states not implemented. Only the **processing** and **completed** states are required to be implemented by an agent. However, a conforming management application SHALL be prepared to accept any of the states in the job life cycle specified here, so that the management application can interoperate with any conforming agent.

The job states are intended to be user visible. The agent SHALL make these states visible in the MIB, but only for the subset of job states that the implementation has. Some implementations MAY need to have sub-states of these user-visible states. The **jmJobStateReasons1** object and the **jobStateReasons*N*** (***N***=**2..4**) attributes can be used to represent the sub-states of the jobs.

Job states are intended to last a user-visible length of time in most implementations. However, some jobs may pass through some states in zero time in some situations and/or in some implementations.

The job model does not specify how accounting and auditing is implemented, except to assume that accounting and auditing logs are separate from the job life cycle and last longer than job entries in the MIB. Jobs in the **completed, aborted,** or **canceled** states are not logs, since jobs in these states are accessible via SNMP protocol operations and SHALL be removed from the Job Monitoring MIB tables after a site-settable or implementation-defined period of time. An accounting application MAY copy accounting information incrementally to an accounting log as a job processes, or MAY be copied while the job is in the **canceled, aborted,** or **completed** states, depending on implementation. The same is true for auditing logs.

The jmJobState object specifies the standard job states. The normal job state transitions are shown in the state transition diagram presented in Table 1.

6. APPENDIX B - Support of the Job Submission ID in Job Submission Protocols

This appendix lists the job submission protocols that support the concept of a job submission ID and indicates the attribute used in that job submission protocol.

6.1 Hewlett-Packard's Printer Job Language (PJL)

Hewlett-Packard's Printer Job Language provides job-level printer control and printer status information to applications. The PJL JOB command is used at the beginning of a print job and can include options applying only to that job. A PJL JOB command option has been defined to facilitate passing the **JobSubmissionID** with the print job, as required by the Job Monitoring MIB. The option is of the form:

```
SUBMISSIONID = "id string"
```

Where the "id string" is a string and SHALL be enclosed in double quotes. The format is as described for the **jmJobSubmissionID** object.

The entire PJL JOB command with the optional parameter would be of the form:

```
@PJL JOB SUBMISSIONID = "id string"
```

See "Printer Job Language Technical Reference Manual", part number 5021-0328, from Hewlett-Packard for complete information on the PJL JOB command and the Printer Job Language.

NOTE - Some PJL implementations wrap a banner page as a PJL job around a job submitted by a client. In this case, there will be two job submission ids. The outer one being the one with the banner page and the inner one being the original user's job. The agent SHALL use the last received job submission ID for the jmJobSubmissionID index, so that the original user's job submission ID will be used, not the banner page job ID.

6.2 ISO DPA

The ISO 10175 Document Printing Application (DPA) protocol specifies the "**job-client-id**" attribute that allows the client to supply a text string ID for each job.

7. References

[char-set policy] Harald Avelstrand, "IETF Policy on Character Sets and Language", June 1997. Latest draft: <draft-avelstrand-charset-policy-00.txt>

[GB2312] GB 2312-1980, "Chinese People's Republic of China (PRC) mixed one byte and two byte coded character set"

[hr-mib] P. Grillo, S. Waldbusser, "Host Resources MIB", RFC 1514, September 1993

[iana] J. Reynolds, and J. Postel, "Assigned Numbers", STD 2, RFC 1700, ISI, October 1994.

[IANA-charsets] Coded Character Sets registered by IANA and assigned an enum value for use in the **CodedCharSet** textual convention imported from the Printer MIB. See ftp://ftp.isi.edu/in-notes/iana/assignments/character-sets

[iana-media-types] IANA Registration of MIME media types (MIME content types/subtypes). See ftp://ftp.isi.edu/in-notes/iana/assignments/

[ISO 646] ISO/IEC 646:1991, "Information technology -- ISO 7-bit coded character set for information interchange", JTC1/SC2.

[ISO 8859] ISO/IEC 8859-1:1987, "Information technology -- 8-bit single byte coded graphic character sets - Part 1: Latin alphabet No. 1, JTC1/SC2."

[ISO 2022] ISO/IEC 2022:1994 - "Information technology -- Character code structure and extension techniques", JTC1/SC2.

[ISO-10646] ISO/IEC 10646-1:1993, "Information technology -- Universal Multiple-Octet Coded Character Set (UCS) - Part 1: Architecture and Basic Multilingual Plane, JTC1/SC2.

[iso-dpa] ISO/IEC 10175 Document Printing Application (DPA). See **ftp://ftp.pwg.org/pub/pwg/dpa/**

[ipp-model] Internet Printing Protocol (IPP), work in progress on the IETF standards track. See **draft-ietf-ipp-model-01.txt**. See also **http://www.pwg.org/ipp/index.html**

[JIS X0208] JIS X0208-1990, "Japanese two byte coded character set."

[mib-II] MIB-II, RFC 1213.

[print-mib] The Printer MIB - RFC 1759, proposed IETF standard. Also an Internet-Draft on the standards track as a draft standard: **draft-ietf-printmib-mib-info-02.txt**

[req-words] S. Bradner, "Keywords for use in RFCs to Indicate Requirement Levels", RFC 2119, March 1997.

[rfc 1738] Berners-Lee, T., Masinter, L., McCahill, M., "Uniform Resource Locators (URL)", RFC 1738, December 1994.

[rfc 2130] C. Weider, C. Preston, K. Simonsen, H. Alvestrand, R. Atkinson, M. Crispin, and P. Svanberg, "The Report of the IAB Character Set Workshop held 29 Feb-1 March, 1997", April 1997, RFC 2130.

[SMIv2-TC] J. Case, et al. “Textual Conventions for Version 2 of the Simple Network Management Protocol (SNMPv2)”, RFC 1903, January 1996.

[tipsi] IEEE 1284.1, Transport-independent Printer System Interface (TIPSI).

[URI-spec] Berners-Lee, T., Masinter, L., McCahill, M. , "Uniform Resource Locators (URL)", RFC 1738, December, 1994.

[US-ASCII] Coded Character Set - 7-bit American Standard Code for Information Interchange, ANSI X3.4-1986.

[UTF-8] F. Yergeau, "UTF-8, a transformation format of Unicode and ISO 10646", RFC 2044, October 1996.

8. Author's Addresses

Ron Bergman
Dataproducts Corp.
1757 Tapo Canyon Road
Simi Valley, CA 93063-3394

Phone: 805-578-4421
Fax: 805-578-4001
Email: rbergman@dpc.com

Tom Hastings
Xerox Corporation, ESAE-231
701 S. Aviation Blvd.
El Segundo, CA 90245

Phone: 310-333-6413
Fax: 310-333-5514
EMail: hastings@cp10.es.xerox.com

Scott A. Isaacson
Novell, Inc.
122 E 1700 S
Provo, UT 84606

Phone: 801-861-7366
Fax: 801-861-4025
EMail: scott_isaacson@novell.com

Harry Lewis
IBM Corporation
6300 Diagonal Hwy
Boulder, CO 80301

Phone: (303) 924-5337
Fax:
Email: harryl@us.ibm.com

Send comments to the printmib WG using the Job Monitoring Project (JMP)
Mailing List: jmp@pwg.org

To learn how to subscribe, send email to: jmp-request@pwg.org

For further information, access the PWG web page under "JMP":
http://www.pwg.org/

Other Participants:

Chuck Adams - Tektronix
Jeff Barnett - IBM
Keith Carter, IBM Corporation
Jeff Copeland - QMS
Andy Davidson - Tektronix
Roger deBry - IBM
Mabry Dozier - QMS
Lee Ferrel - Canon
Steve Gebert - IBM
Robert Herriot - Sun Microsystems Inc.
Shige Kanemitsu - Kyocera
David Kellerman - Northlake Software
Rick Landau - Digital
Harry Lewis - IBM
Pete Loya - HP
Ray Lutz - Cognisys
Jay Martin - Underscore
Mike MacKay, Novell, Inc.
Stan McConnell - Xerox
Carl-Uno Manros, Xerox, Corp.
Pat Nogay - IBM
Bob Pentecost - HP
Rob Rhoads - Intel
David Roach - Unisys
Hiroyuki Sato - Canon

3607 Bob Setterbo - Adobe
3608 Gail Songer, EFI
3609 Mike Timperman - Lexmark
3610 Randy Turner - Sharp
3611 William Wagner - Digital Products
3612 Jim Walker - Dazel
3613 Chris Wellens - Interworking Labs
3614 Rob Whittle - Novell
3615 Don Wright - Lexmark
3616 Lloyd Young - Lexmark
3617 Atsushi Yuki - Kyocera
3618 Peter Zehler, Xerox, Corp.

9. INDEX

This index includes the textual conventions, the objects, and the attributes. Textual conventions all start with the prefix: "**JM**" and end with the suffix: "**TC**". Objects all starts with the prefix: "**jm**" followed by the group name. Attributes are identified with enums, and so start with any lower case letter and have no special prefix.

—M—

—N—

—O—

—P—

—Q—

—S—

—T—